

GIKEN

March.2020

GKL Setting Software Instruction Manual

GIKEN INDUSTRIAL CO., LTD.

Before using it



■ Note

- ① Please read this instruction manual in order to use this product properly.
- ② We prohibit the use or reproduction of part or all of this instruction manual without permission.
- ③ Please don't do it, thinking that handling and operation not described in this instruction manual cannot be done.
In addition, we will exclude defects that occur as a result of handling and operation not described in this instruction manual from the guarantee range.
- ④ The matters described in this manual are subject to change without notice for improvement.
- ⑤ Regarding special products, it may not correspond to this specification.
Please consult us separately.
- ⑥ Setting personal computer is optional.
Please contact us if necessary.



■ Note

If this product is in a dangerous condition, either turn off the power switch of the main unit and the connected device, or unplug the power cord from the outlet. ("Dangerous condition" means a state where the occurrence of fire or danger to the body is expected due to abnormal heat generation, smoke emission, ignition, etc.)

Summary

This software is used to configure the GKL / GKLW controller.

The setting input of GKL · GKL controller can be done manually at the front of the controller. However, since setting input is difficult to understand, we will use this software so that it can be easily understood.

When using the setting personal computer, it is easy to enter the setting by the batch transmission function, and the maintenance is improved.

In addition, this software allows you to read the tightening history etc., display waveforms such as torque, and monitor the operating condition.

Operating environment

OS : Windows XP (32bit、 64bit)
Windows Vista (32bit、 64bit)
Windows 7 (32bit、 64bit)
Windows 8 (32bit、 64bit)

Recommended RAM capacity : Windows XP,Vista : More than 2GB
Windows 7,8 : More than 4GB

※The above RAM capacity is a standard for comfortable use.

Place of installation : C¥GIKEN¥GKLSETTING

Starting method : Please click GKL.exe

Note 1) The initial password for writing to the controller is "2014".

Note 2) Please set the COM port number used for communication with the controller in the C ¥ GIKEN ¥ GKL setting ¥ GKL.ini file.

Note 3) Set the version of the controller that communicates with the setting PC in the C ¥ GIKEN ¥ GKL setting ¥ GKL.ini file.

Note 4) In order to communicate with the setting personal computer, you need to install the USB driver of the controller.

※For details, please refer to "9-1. USB driver installation" and "9-2. About controller and setting personal computer connection".

INDEX

1.Main menu	- 5 -
1-1.Screen composition	- 6 -
1-2.Main menu initial screen	- 7 -
1-3.Communication check, version check function	- 7 -
2.Setting read.....	- 8 -
2-1.File	- 9 -
2-2.Controller	- 10 -
2-3.SD card	- 11 -
3.Setting write.....	- 12 -
3-1.File	- 13 -
3-2.Controller	- 14 -
3-3.SD card	- 15 -
4.Setting	- 16 -
4-1.Common setting	- 17 -
4-1-1.Calendar and basic unit setting	- 18 -
4-1-2.Screw number setting.....	- 24 -
4-2. Position setting.....	- 26 -
4-2-1. Cylinder name setting.....	- 27 -
4-2-2.X rate.set.....	- 29 -
4-2-3.Y rate.set.....	- 31 -
4-2-4.XY point setting(Teaching)	- 33 -
4-2-5.Timer setting	- 43 -
4-3.Nutrunner setting.....	- 45 -
4-3-1.RATE.SET.....	- 46 -
4-3-2.Block control.....	- 48 -
4-3-3.Manual setting.....	- 52 -
4-3-4.Auto setting	- 63 -
4-4.Program setting.....	- 68 -
4-4-1. Tightening block operation select.....	- 70 -
4-4-2. X,Y axis operation select.....	- 71 -
4-5. About reading and writing setting of each setting screen	- 73 -
4-5-1.Each setting read.....	- 73 -
4-5-2.Each setting write.....	- 78 -
5.Auto measurement.....	- 82 -
5-1.Online	- 83 -
5-2.Tightening wave	- 85 -
5-3.Tightening record	- 91 -
5-4.Alarm history.....	- 93 -
5-5.Cycle monitor.....	- 94 -
5-6.Display of current step	- 95 -

6.Quality control	- 96 -
6-1.Gear check result	- 97 -
6-2.Self diagnosis	- 98 -
7.Print/Excel output.....	- 99 -
7-1. Perform online print setting of controller data	- 100 -
7-2.PC setting print	- 101 -
8.I/O monitor	- 102 -
8-1.Monitor	- 103 -
8-2.Dummy input	- 104 -
8-3.Dummy output	- 105 -
9.Other	- 106 -
9-1.About USB driver	- 106 -
9-2. Regarding controller and setting PC connection	- 106 -
9-3.About creation of tightening program	- 106 -
9-4. About Operation preparation OFF of configuration reading	- 107 -
The terminology explanation	- 108 -

1.Main menu





Fig (1-1) Main menu

- Setting read (F1) The setting data is read from file , controller , and SD card.
- Setting write (F2) The setting data is written to file , controller or SD card.
- Setting(F3) The setting menu is displayed.
- Auto measurement(F4) The auto measurement menu is displayed.
- Quality control (F5) The quality control screen is displayed.
- Print/Excel output(F6) The print and excel output menu is displayed.
- I/O Monitor(F7) The I/O monitor menu is displayed.
- Exit(F12) Exit the program.

1-1. Screen composition

The screen of the GKL setting software is shown in the figure below.
The configuration itself is not different from GSK.



1-2.Main menu initial screen

When the application is started, it automatically gets the data of the GKL controller. Inquiry "Do you want to communicate?" is coming when the application is started. In this time if you select "Yes", version and communication check will be started. If you select "No", you enter the main menu without communication.




Fig.(1-2): "Do you want to communicate?"

1-3.Communication check, version check function

If you select "Yes" in the above "1-2 Main menu initial screen", automatically GKL controller does communication check, and the version check.




Fig.(1-3): Initial communication check error




Fig.(1-4): Unit setting acquisition error(※)






Fig.(1-5): Controller version check error

2.Setting read

Select "Setting read" from the main menu, the following screen will be displayed.
In this item, GKL setting data is read from file, controller, SD card.




Fig.(2-1): Setting read screen

[Button]

·File(F1)

It reads the GKL configuration file from some folder.

·Controller(F2)

It reads the GKL configuration file from the controller.
If you read the configuration file from the GKL controller,
the controller and computer must be connected by a USB cable.

·SD card(F3)

You can save the settings of GKL controller to the SD card
as a file.
You can read the GKL settings from the SD card
by the configuration PC.

·Return(F12)

Press this button to return to the main menu.

2-1.File




Fig.(2-2): Selection of the read files

For reading file selection, please select the file with "file extension: GKL".
When reading the SD card file, please select file extension: SD "file is read."

You select the GKL configuration file to read in the file selection dialog.



Fig.(2-3): Reading files from the folder

When you select a file, reading will start. You can see how the GKL setting data is read. The GKL configuration file has the following settings.

Unit setting	Screw number setting
Nut runner setting	Position setting
Program setting	

※GKL configuration file will not be saved the following setting

Tightening output setting	Calendar setting
Option setting	Auto setting

When the reading GKL configuration file is complete, the following message is displayed. After the reading, it goes to the "Main menu".




Fig.(2-4): Finish reading configuration file

2-2.Controller

It reads the settings saved in the GKL controller.

When reading the setting from the GKL controller, it is necessary that the GKL controller and the personal computer are connected with a USB cable.




Fig.(2-5): Reading files from the controller




Fig.(2-6): Finish reading configuration file

When the reading from the controller is finished, you will see a message in the Fig (2-6). After the reading settings from the controller, it goes to the "Main menu".

2-3.SD card

It reads the GKL setting file (extension: SD) saved on the SD card.

※The setting value saved on the SD card using the display function of GKL is the extension SD.

Since reading in this case reads the file with the extension SD, there is no need for the SD card to be inserted in the personal computer.




Fig.(2-7): SD data reading




Fig.(2-8):SD data read complete message

When loading of SD data is completed, the message shown in Figure 2-8 is displayed. After loading of SD data is finished, it will automatically move to "Main Menu".

3.Setting write

Select "Setting write" from "Main Menu", the following screen will be displayed. In this case, write the setting to "hard disk drive of connected computer", controller and SD card.




Fig.(3-1):Write Settings Screen

- File (F1) It will write the GKL setting to the file of the extension GKL.
- Controller (F2) It will write the GKL setting to the GKL controller. When it writes the setting to the GKL controller, it is necessary that the controller and the personal computer are connected with the USB cable.
- SD card (F3) You will write the GKL setting to the extension SD file.
- Return (F12) You will return to the main menu.

3-1.File

In the file writing process, it writes the GKL setting information to the HDD (hard disk drive) of the personal computer or other files on accessible media.

The GKL setting file with setting information is saved with the file extension: GKL.




Fig.(3-2). Write dialog

It uses the file selection dialog and writes the GKL setting to the file.



Fig.(3-3). Progress of file writing




Fig.(3-4). GKL setting file write completion message

When you select a file, writing begins and the progress of writing the GKL setting file is displayed. (Fig. (3-3))

When the writing of the GKL setting file is completed, the message shown in Figure (3-4) is displayed.

When you press the OK button, you will automatically go to the main menu screen.

3-2.Controller

Here we write the GKL setting to the controller.

When writing to the controller, it is necessary that the GKL controller and the personal computer are connected with a USB cable.

A password is required to write to the controller. (Password: 2014)

If the password is unknown, it can not be written to the controller.




Fig.(3-5): Confirm password




Fig.(3-6): Confirm preparation OFF

After confirming the password, it will move on to Fig. (3-6) screen.

Please select "Yes" if you can turn off preparation for driving.

Writing can not be done unless driving preparation is turned off.



Fig. (3-7) Progress status of controller writing




Fig. (3-8): Controller write completion message

When writing to the controller is completed, the message of Fig. (3-8) is displayed. When you press the OK button in that figure, it automatically moves to the main menu screen.

3-3.SD card

In the file writing process, it writes the GKL setting information as a file with extension: SD that can be read by the GKL controller.

Although this setting file can be written directly to the SD card connected to the personal computer, it can be saved once in a folder such as "UserFile" and then transferred to the SD card.




Fig. (3-9): Select write file

You will use the file selection dialog to decide where to write the configuration file and the name of the file




Fig. (3-10): Progress status of file writing




Fig. (3-11): Write file completion message

When you press the "save" button in the dialog, writing starts.

When writing starts, the screen changes to the writing progress of the setting file.

When writing of the setting file is completed, the message

in the upper right figure is displayed, and when you press the "OK" button, it returns to the main menu.

4.Setting

If "Setting" is selected in the main menu, the screen shown below will be displayed.




Fig. (4-1):Setting menu

[Button]

- | | |
|---------------------------|---------------------------------------|
| • Common setting (F1) | Common setting menu is displayed. |
| • Position setting (F2) | Position setting menu is displayed. |
| • Nut runner setting (F3) | Nut runner setting menu is displayed. |
| • Program setting (F4) | Program setting menu is displayed. |
| • Return (F12) | It will return to Main Menu. |

4-1.Common setting

When you select "common setting" in "Setting menu", the screen shown below will be displayed.




Fig. (4-2):Common setting menu

[Button]

- Calendar and basic unit setting (F1) It displays the "Calendar and basic unit setting menu".
- Screw number setting (F2) It displays the "Screw number setting".
- Return to the setting menu (F12) You can return to the setting menu.

4-1-1. Calendar and basic unit setting

If you select "Calendar / basic unit setting" in "common setting", the screen shown below will be displayed.

If you press the button, communication starts and you get the software version displayed in the version information on the upper right.

If it is not connected or communication fails, the version information will be blank as shown below.




Fig. (4-3): Calendar and basic unit setting

[Button]

- Calendar setting (F1) It displays the "Calendar setting"
- Unit setting (F2) It displays the "Unit setting".
- Tightening data output setting (F3) It displays the "Tightening data output setting"
- Option setting(F4) It displays the "Option setting".
- Return to the common setting (F12) To return to the "Common setting menu".

[Item]

- Version information It displays the version of the controller and interface.

4-1-1-1.Calendar setting

If you select "Calendar Setting" in "Calendar / Basic Unit Setting", the following screen will appear.

On the screen shown below, you can display the controller's calendar information and set the PC's calendar information in the controller.




Fig. (4-4): Calendar setting

[Item]

- Date, time Here we display date and time information the controller currently has.

[Button]

- Setting It sets the calendar information of the PC to the controller.
- Return You can return to the "Calendar and basic unit setting".

4-1-1-2. Unit setting

When "Unit Setting" is selected in "Calendar / basic unit setting", the screen shown below will be displayed.

Here, you set the role of the unit to which each axis belongs and the motor to which the axis moves.




Fig. (4-5): Unit setting

[Item]

- Unit No. It has to display the affiliation unit of the axis. You can set from 1 to 4 when X, Y or Z is selected in the lower type, and 1 to 7 if it is not.
- Kind It displays the type of axis. N: Nut runner, X: x-axis, Y: y-axis, Z: z-axis
- Read It displays the loading screen of the unit configuration.
- Write It displays the writing screen of the unit configuration.
- OK It is to accept the changes and return to the calendar and basic unit setting menu.
- Cancel It erases the changes and return to the calendar and basic unit setting menu.



Screen printing: This prints the current screen as it is.

4-1-1-3. Tightening data output setting

This sets the tightening data output from the controller and the output contents of Ch10.

The screenshot shows a software window titled "Tightening data output" with the following settings:

- Axis determination transmission Yes/No: Transmission No
- Screw number transmission Yes/No: Transmission No
- Engine No. digit setting: 0
- Output timing setting: Data transmission after the tightening total determination output
- Transmission digit setting: No transmission
- Unit number transmission Yes/No: Transmission No
- Program number transmission Yes/No: Transmission No
- Date and Time transmission Yes/No: Transmission No
- Printer/data output switching setting: Operation as a printer board

Buttons at the bottom include Read, Write, Print, OK, and Cancel.

Fig. (4-6): Tightening data output setting

[Item]

- Axis determination transmission
This item determines whether to include judgment for each tightening target in the output data to the outside.
- Screw number transmission
It sets whether to include the number to be tightened in the output data to the outside.
- Engune No. digit setting
In this item, you select the number of display digits of the engine No. from the following numbers.
0: Do not transmit
1 to 8: Number of digits
- Output timing setting
Here you select the timing to output tightening data.
- Transmission digit setting
Here you select the number of digits of the output data such as torque, angle, slope, time etc.
- Unit number transmission
You set whether to transmit the unit number.
- Program number transmission
In this item, you set whether to include program number in transmission of tightening data.
- Date and time transmission
You choose the description of the date and time of the tightening result to be output.

- Printer / data output switching setting
You select the CN 10 function of the GKL interface from among the setting items.

[Button]

- Read It displays the loading screen of tightening data output settings.
- Write It displays the writing screen of tightening data output settings.
- Print It runs the printing of tightening data output settings.
- OK It is to accept the changes and return to the calendar and basic unit setting menu.
- Cancel It erases the changes and return to the calendar and basic unit setting menu.



Screen printing: This prints the current screen as it is.

4-1-1-4.Option setting

When "Option setting" is selected in "calendar / basic unit setting menu", the screen shown below will be displayed.




Fig. (4-7): Option setting

[Item]

- M-NET start address setting
In this item, we will set the address of GKL in M-NET.
- M-NET I/O monitor unit selection
Here, you select the unit that displays the signal etc. in Fn.3 of the 7 SEG monitor on the GKL controller.
It shows the internal state of the interface when 0 is set, and the status of the input / output signal of that unit number when 1 ~ 7 is set.
- External display indication setting
It sets the display language of GKL attached monitor.

[Button]

- Read It displays the loading screen of option setting.
- Write It displays the writing screen of option setting.
- Print It runs the printing of option setting.
- OK It is to accept the changes and return to the calendar and basic unit setting menu.
- Cancel It erases the changes and return to the calendar and basic unit setting menu.

 Screen printing: This prints the current screen as it is.

4-1-2.Screw number setting

When "Screw number array" is selected in "common setting", the screen shown below will be displayed.

Here we set the axis alignment to be displayed on the external display of GKL.




Fig. (4-8): Screw number setting

[Item]

- PROGRAM No. It set the program number you want to set.
- Screw No. Select You select the screw number you want to plot.
- Axis array setting form It will set the axis arrangement with the left click of the mouse to this place.
- SCREW No. The number of screw to be set
- DISP No . The number to display
- Big marker It displays the marker of the screw number to be plotted on the axis array form in big size.
- Small marker It displays the marker of the screw number to be plotted on the axis array form in small size.

[Button]

- Read It displays the loading screen of option setting.
- Write It displays the writing screen of option setting.
- Print the screen It runs the printing of option setting.
- Clear All the array data on the configuration form to delete.
- Delete one It will remove the marker of the screw number that has been selected on the configuration form.
- OK It is to accept the changes and return to the setting menu.
- Cancel It erases the changes and return to the setting menu.



Screen printing: This prints the current screen as it is.



Undo : Undo changes



Copy : Copies the settings for each program number.



Paste : Paste the information acquired by copying to the specified program number.

4-2. Position setting

When you select "Positioning setting" from "Setting" menu, the screen shown below will be displayed.

Here, we will set the positioning used in the XY axis motion selection in "Program setting".




Fig. (4-9): Position setting

[Button]

- Cylinder name setting(F1) In this item, we set the type and orientation of the cylinder.
- X rate. Set(F2) In this item, we will set the rating of the motor used for the X axis.
- Y rate. Set(F3) In this item, we will set the rating of the motor used for the Y axis.
- XY point setting(Teaching)(F4) In this item we will register coordinates to use for positioning. Also, when using the Z axis, we set the rating of the motor to be used for the Z axis within this item.
- Timer setting(F5) In this item, we will set the maximum waiting time for interference prevention and the time upper limit for positioning operation.
- Return to the setting menu(F12) You can return to the setting menu.

4-2-1. Cylinder name setting

When you select "Cylinder name setting" from "Positioning setting", the screen shown below opens.




Fig. (4-10): Cylinder name setting

If you set the cylinder name, the character of name on the IO monitor is changed to it. (example) Cylinder1 advance ⇒ N/R 1 descent


One cylinder can be set for each unit.

Even if you set a number that exceeds the number of units to be used, it can not be used in "program setting" which sets the operation.

[Item]

- Cylinder use number You select the number of cylinders to be used. You can set up to 4, the maximum number of units. The number of cylinders selected here can be set below.
- Cylinder name setting In this case, you select the name to be moved by the target cylinder. (NR, socket etc.)

On the right side of the name setting, you can select the movement direction. (Ascending / descending, forward / backward etc.)



[Button]

- Read It displays the loading screen of Cylinder name setting.
- Write It displays the writing screen of Cylinder name setting.
- Print It runs the printing of Cylinder name setting.
- OK This will return to the positioning setting menu while keeping the change contents.
- Cancel It returns to the positioning setting menu without holding the change contents. Even if you press the confirm button, if you return with this button, the change will be reset.



Print screen: Print the current screen as it is.



Undo: Undo changes.

4-2-2.X rate.set

When you select "X axis rating" from "Position setting", the following screen will be displayed.

Here we set the rating of the X axis positioning motor.

Parameter	Value
Setting No.	1
Acceleration	32767 10rpm/sec max 2000 10rpm/sec
Deceleration	32767 10rpm/sec max 2000 10rpm/sec
Move speed	750mm/sec max 350 mm/sec
Point coordinates	100 mm max 10 mm
Extent output1 down limit	3276.7 mm max 200.0 mm
Extent output1 up limit	3276.7 mm max 200.0 mm
Extent output2 down limit	3276.7 mm max 200.0 mm
Extent output2 up limit	3276.7 mm max 200.0 mm
Motor 1 rotate move	32.767 mm/rev max 10.000 mm/rev
Motor model	TS4603
Rotate direction	CW Motor 0 home position ccw

Fig. (4-11): X rate. screen

[Item]

- Setting No. In this item, we will select the X rated number to be set.
- Acceleration(Input range: 0 to 32767)
Here we set the acceleration constant at which the positioning motor reaches the moving speed from the start of operation.
- Deceleration(Input range: 0 to 32767)
It sets the deceleration constant that the motor reaches the operation stop from moving speed.
- Move speed(Input range: ["Motor 1 rotate move" * 75])
It sets the movement speed.
- Point coordinate(Input range: 0 to 100)
It sets the range to be detected as the point when you point output in the external communication output signal.
- Extent output 1 down limit(Input range: 0 to 3276.7)
It sets the lower limit value of the area that outputs the X range output 1 of the output signal.
- Extent output 1 up limit(Input range: 0 to 3276.7)
It sets the upper limit value of the area that outputs the X range output 1. If the current position of the X coordinate is between the lower limit and the upper limit of the range output, the output signal "X range output 1" turns ON.
- Extent output 2 down limit(Input range: 0 to 3276.7)
It sets the lower limit value of the area that outputs the X range output 2 of the output signal.
- Extent output 2 up limit(Input range: 0 to 3276.7)
It sets the upper limit value of the area that outputs the X range output 2. If the current position of the X coordinate is between the lower limit and the upper limit of the range output, the output signal "X range output 2" turns ON.

4-2-3. Y rate.set

When you select "Y axis rating" from "Position setting", the following screen will be displayed.

Here we set the rating of the Y axis positioning motor.

Parameter	Current Value	Max Value	Unit
Acceleration	32767	10rpm/sec max	2000 10rpm/sec
Deceleration	32767	10rpm/sec max	2000 10rpm/sec
Move speed	750mm/sec max	350	mm/sec
Point coordinates	100 mm max	10	mm
Extent output1 down limit	3276.7 mm max	200.0	mm
Extent output1 up limit	3276.7 mm max	200.0	mm
Extent output2 down limit	3276.7 mm max	200.0	mm
Extent output2 up limit	3276.7 mm max	200.0	mm
Motor 1 rotate move	32.767 mm/rev max	10.000	mm/rev
Motor model	TS4603		
Rotate direction	CW - Motor 0 home position ccw		

Fig. (4-12): Y rate. screen

[Item]

- Setting No. In this item, we will select the Y rated number to be set.
- Acceleration(Input range: 0 to 32767)
Here we set the acceleration constant at which the positioning motor reaches the moving speed from the start of operation.
- Deceleration(Input range: 0 to 32767)
It sets the deceleration constant that the motor reaches the operation stop from moving speed.
- Move speed(Input range: ["Motor 1 rotate move" * 75])
It sets the movement speed.
- Point coordinate(Input range: 0 to 100)
It sets the range to be detected as the point when you point output in the external communication output signal.
- Extent output 1 down limit(Input range: 0 to 3276.7)
It sets the lower limit value of the area that outputs the Y range output 1 of the output signal.
- Extent output 1 up limit(Input range: 0 to 3276.7)
It sets the upper limit value of the area that outputs the Y range output 1. If the current position of the Y coordinate is between the lower limit and the upper limit of the range output, the output signal "Y range output 1" turns ON.
- Extent output 2 down limit(Input range: 0 to 3276.7)
It sets the lower limit value of the area that outputs the Y range output 2 of the output signal.
- Extent output 2 up limit(Input range: 0 to 3276.7)
It sets the upper limit value of the area that outputs the Y range output 2. If the current position of the Y coordinate is between the lower limit and the upper limit of the range output, the output signal "Y range output 2" turns ON.

4-2-4.XY point setting(Teaching)

This item opens when you select "XY point teaching" from "Position setting menu". Here we set the coordinate of the tightening point and Z axis rating.




Fig.(4-13):Communication confirmation

When "XY point teaching" is selected, communication confirmation is done on the screen of the above figure.

If you do not communicate, please select "No" as it is.

When communicating, please select either "Acquire setting point only" or "Always perform communication" and select "Yes".

[Setting point try]

When entering the XY point teaching screen, you acquire the set coordinates and enter. The current coordinates are not read.

[All the time communication]

It acquires the set coordinates when entering the XY point teach screen and updates the current coordinates in real time with real time.





Fig.(4-14):Teaching screen

[Item]

- X Y N o .

Here we select the unit number that uses the selected coordinate system.

< X Y axes >

- X home position

When the X axis of the target unit is the origin, "Home position OK" is lit, otherwise it will light "Home position NG". Neither will shine when not communicating.

- Y home position

When the X axis of the target unit is the origin, "Home position OK" is lit, otherwise it will light "Home position NG". Neither will shine when not communicating.

- X sarvo condition
This item indicates whether drive power is supplied to the X axis motor.
"Servo ON" lights up when power is supplied to the X axis motor, and "Servo OFF" lights when power is not supplied.
"Servo ON" lights up when not communicating.
 - Y sarvo condition
This item indicates whether drive power is supplied to the Y axis motor.
"Servo ON" lights up when power is supplied to the Y axis motor, and "Servo OFF" lights when power is not supplied.
"Servo ON" lights up when not communicating.
- JOG move speed
- X axis
In this item, set the movement speed of X axis coordinate during JOG operation.
The unit is [mm / sec].
 - Y axis
In this item, set the movement speed of Y axis coordinate during JOG operation.
The unit is [mm / sec].
 - X rotation direction
When the manual JOG operation is started and the destination coordinate number is not specified, the X axis moves at the jog moving speed in the direction specified here.
 - Y rotation direction
When the manual JOG operation is started and the destination coordinate number is not specified, the Y axis moves at the jog moving speed in the direction specified here.
 - Manual JOG
The JOG operation is started with the following three kinds of buttons here.
The JOG operation is performed only while this button is held down.
 - X Y execution
The X axis and the Y axis simultaneously perform JOG operation.
 - X execution
JOG operation is performed only on the X axis.
 - Y execution
JOG operation is performed only on the Y axis.

< Z axis >

※ This screen is not displayed unless you have the Z axis motor in the unit setting.

- Z home position
When the Z axis of the target unit is the origin, "Home position OK" is lit, otherwise it will light "Home position NG". Neither will shine when not communicating.
 - Z sarvo condition
This item indicates whether drive power is supplied to the Z axis motor. "Servo ON" lights up when power is supplied to the Z axis motor, and "Servo OFF" lights when power is not supplied. "Servo ON" lights up when not communicating.
 - Mnuual JOG
JOG operation is started with the button here. For the Z axis, set the jog moving speed with "Z rate. Set". You can also use the "Up" and "Down" buttons to perform the direction and the execution on the "XY axis".
 - Z rate. Set
Here we set the rating of the Z axis positioning.
- ## < Teaching >
- Teaching exection
It sets the current coordinates to the coordinate's cell of the specified point in the table. And furthermore, it writes registered coordinate data to the controller by this function.
 - Coordinates setting
The points from 1 to 160 and the coordinates list of the origin position and relay point are displayed. Please click on the leftmost column to specify the point. If the point number column turns yellow, it is in selected state.
 - Coordinates read
It reads the coordinate values that are currently registered from the controller. If reading fails, all the values set here are initialized, including interference area setting. However, since initialization is only on the setting software, initialized values are not written to the controller.
 - Coordinates entry
It registers the coordinate values that are displayed on the screen to the controller. You can change the coordinate value by entering it directly into the cell and pressing this button.
 - Coordinates clear
This sets the coordinate value of the specified point to 0. (Since we send a write command to the controller, it is not necessary to register the coordinates after clearing the coordinates again.)

• Interference setting

Pressing this button moves the screen to the interference area setting screen. In the interference area setting, you can specify whether you can specify the area that can be manually entered, set the adjacent interference area, and enable it. In order to enter this screen, it is necessary to enter a password.

• Coordinates shift

All the coordinates set in the coordinate setting table are shifted on the screen below.

※When the coordinate value is 0, it is not shifted.

(ex.) :When (20, 0) is shifted by (30, 40), it becomes (50, 0).




Fig.(4-15):Coordinates shift screen

• X coordinate

This column displays the current coordinate value of the X axis.

• Y coordinate

This column displays the current coordinate value of the Y axis.

• Z coordinate

This column displays the current coordinate value of the Z axis.

 Print screen: Print the current screen as it is.

 Undo: Undo changes.

 Copy: It copies the setting contents for each setting number.

 Paste: It pastes the information acquired by copying to the specified setting number.

4-2-4-1.Z rate. set




Fig.(4-16):Z rate setting screen

[Item]

- Acceleration(Input range: 0 to 32767)
Here we set the acceleration constant at which the positioning motor reaches the moving speed from the start of operation.
- Deceleration(Input range: 0 to 32767)
It sets the deceleration constant that the motor reaches the operation stop from moving speed.
- Move speed(Input range: ["Motor 1 rotate move" * 75])
It sets the movement speed.
- Point coordinate(Input range: 0 to 100)
It sets the range to be detected as the point when you point output in the external communication output signal.
- Return position (Up limit)
This setting is the maximum value on the rising side of the Z axis.
In this item, the position where the axis hits in the upward direction is assumed to be 0.
And it sets how many millimeters down from that state.
- Returning amount(relative distance)
This setting is the amount of return when "Cylinder relative return" command is input in program setting.
※It can be used only when TAD 8811 is selected for driver type.
- Down limit
This sets the maximum descent position of the Z axis.
In this item, the position where the axis hits in the upward direction is assumed to be 0.
And it sets how many millimeters down from that state.
This setting also shows the "soft limit" on the Z axis.

4-2-4-2. Interference setting

When you select "Interference area setting" from "XY point teach", the following screen will be displayed.

Here we set the interference area of the XY unit.




Fig.(4-17):Interference setting

[Item]

- X axis + soft limit, X axis - soft limit,
Y axis + soft limit, Y axis - soft limit (Input range: -3276.7 to 3276.7)
: Here we set the operable area for each direction of the X and Y axes.
Coordinates exceeding this value can not be registered manually.
When it tries to move to a point where the coordinate value exceeds this range,
the software limit position is regarded as the target position and it operates.
No abnormality is output after operation.
Judge that operation has ended normally and proceed to the next step.
- Adjacent interference distance setting
: This setting selects whether it uses or does not use
adjacent interference distance setting.

[Button]


- Establish It establish the change contents.
- Write It displays the writing screen of Interference setting
- Print It runs the printing of Interference setting
- O K It retains the changes and returns
to the XY point setting screen.
- Cancel It returns to the XY point setting screen
without holding the change contents.

 Print screen: Print the current screen as it is.

 Undo: Undo changes.

- interference setting① - ⑯ (Input range: 0 to 32767)
- : This sets the interference distance with the adjacent positioning unit.
The X and Y axes that have entered the specified adjacent interference distance stop.
In this setting, the location of the distance indicated by each number changes according to the setting of the equipment type "Fn.6 - 00".
When entering the adjacent interference distance and exceeding the interference wait abnormality setting of the timer setting screen, "interference wait error" is output to the PLC.

① Standard equipment



Unit arrangement example of standard equipment

If you set "0000" with "Fn.6 - 00", it will be recognized as GKL standard equipment. Maximum values that do not interfere in the X axis direction of each unit in the above figure are 1X, 2X, 3X, and 4X, respectively. Assuming that the maximum values that do not interfere in the Y axis direction are 1Y, 2Y, 3Y, 4Y, the values indicated by each number at this time are as follows.

Interference setting①

The distance that unit 1 and unit 3 interfere as it moves further in the X axis direction
This calculates the value to be set by the formula of "setting value = 1X + 3X".

Interference setting②

Distance to interfere if unit 1 and unit 2 advance further in the Y axis direction
This calculates the value to be set by the expression "setting value = 1Y + 2Y".

Interference setting③

Distance to interfere if unit 2 and unit 4 move further in the X axis direction
This calculates the value to be set by the formula of "setting value = 2X + 4X".

Interference setting④

Distance to interfere if unit 3 and unit 4 move further in the Y axis direction
This calculates the value to be set by the formula of "setting value = 3Y + 4Y".

Interference setting⑤

Distance to interfere if unit 2 and unit 3 go further in the X axis direction
This calculates the value to be set by the formula of "setting value = 2X + 3X".

Interference setting⑥

Distance at which the unit 2 and the unit 3 interfere as it proceeds further in the Y axis direction
This calculates the value to be set by the expression of "setting value = 2Y + 3Y".

Interference setting⑦

The distance that unit 1 and unit 4 interfere as it moves further in the X axis direction
This calculates the value to be set by the expression "setting value = 1X + 4X".


Interference setting⑧

Distance to interfere if unit 1 and unit 4 go further in the Y axis direction
This calculates the value to be set by the expression "setting value = 1Y + 4Y".

Interference setting⑨~⑯

There is no need to set it because it is a spare.

②Special facilities 1



Unit arrangement example of special equipment 1

If you set "0001" with "Fn.6 - 00", it will be recognized as special equipment 1 in GKL. Maximum values that do not interfere in the X axis direction of each unit

in the above figure are 1X, 2X, 3X, and 4X, respectively.

Assuming that the maximum values that do not interfere in the Y axis direction are 1 Y, 2 Y, 3 Y, and 4 Y, the respective values indicated by the interference distances are as follows.

interference setting①

The distance that unit 1 and unit 2 interfere as it moves further in the X axis direction
This calculates the value to be set by the formula of "setting value = 1X + 2X".

Interference setting②

Distance at which the unit 2 and the unit 3 interfere as it proceeds further
in the Y axis direction

This calculates the value to be set by the expression of "setting value = 2Y + 3Y".

Interference setting③

Distance to interfere if unit 3 and unit 4 move further in the X axis direction

This calculates the value to be set by the formula of "setting value = 3X + 4X".

Interference setting④

Distance to interfere if unit 1 and unit 4 go further in the Y axis direction

This calculates the value to be set by the expression "setting value = 1Y + 4Y".

Interference setting⑤

The distance that unit 1 and unit 3 interfere as it moves further in the X axis direction

This calculates the value to be set by the formula of "setting value = 1X + 3X".

Interference setting⑥

Distance at which the unit 1 and the unit 3 interfere as it proceeds further
in the Y axis direction

This calculates the value to be set by the expression of "setting value = 1Y + 3Y".

Interference setting⑦

Distance to interfere if unit 2 and unit 4 move further in the X axis direction

This calculates the value to be set by the formula of "setting value = 2X + 4X".

Interference setting⑧


Distance to interfere if unit 2 and unit 4 move further in the Y axis direction

This calculates the value to be set by the formula of "setting value = 2Y + 4Y".

Interference setting⑨~⑯

There is no need to set it because it is a spare.

③Special facilities 2



Unit arrangement example of special equipment 2

If you set "0002" with "Fn.6-00", it will be recognized as special equipment 2 in GKL.

Maximum values that do not interfere in the X axis direction of each unit

in the above figure are 1X, 2X, 3X, and 4X, respectively.

Assuming that the maximum values that do not interfere in the Y axis direction are 1Y, 2Y, 3Y, 4Y, the values indicated by each number at this time are as follows.

Interference setting①

The distance that unit 1 and unit 2 interfere as it moves further in the X axis direction
This calculates the value to be set by the formula of "setting value = 1X + 2X".

Interference setting②

The distance in the Y direction when unit 1 and unit 2 are brought closer to each other
as they advance further in both the X axis direction and the Y axis direction.

This calculates the value to be set by the expression of "setting value = 2Y - 3Y".

Interference setting③

Distance to interfere if unit 2 and unit 3 go further in the X axis direction

This calculates the value to be set by the formula of "setting value = 2X - 3X"

Interference setting④

The distance in the X direction when unit 2 and unit 3 are brought closer to each other
as they advance further in both the X axis direction and the Y axis direction.

This calculates the value to be set by the expression of "setting value = 2Y + 3Y"

Interference setting⑤

The distance in the X direction when unit 1 and unit 2 are advanced by both the X axis
direction and the Y axis direction as far as they interfere with each other.

This calculates the value to be set by the formula of "setting value = 1X + 2X".

Interference setting⑥

The distance in the X direction when unit 2 and unit 3 are brought closer to each other
as they advance further in both the X axis direction and the Y axis direction.

This calculates the value to be set by the formula of "setting value = 2X - 3X"

Interference setting⑦~⑩

There is no need to set it because it is a spare.

4-2-5.Timer setting

When you select "Timer setting" from "Position setting", the timer setting screen opens.




Fig. (4-18):Timer setting

Interference fault ⇒ When the standby time due to the setting in the adjacent interference area exceeds this set value, GKL judges that there is an abnormality in operation and outputs "Interference wait error" signal. When this signal is output, GKL will not send other notifications.

Positioning locator fault ⇒ If the JOG operation and the MOV_X MOV_Y MOV_XY operation are not completed within this time, the GKL judges that there is an abnormality in operation and outputs a "positioning error" signal. When this signal is output, GKL will not send other notifications.

[Item]

- Interference 1 fault It sets the interference waiting abnormality of the abnormal unit 1.
- Interference 2 fault It sets the interference waiting abnormality of the abnormal unit 2.
- Interference 3 fault It sets the interference waiting abnormality of the abnormal unit 3.
- Interference 4 fault It sets the interference waiting abnormality of the abnormal unit 4.
- Positioning locator 1 fault It sets the positioning abnormality of the abnormal unit1.
- Positioning locator 2 fault It sets the positioning abnormality of the abnormal unit 2.
- Positioning locator 3 fault It sets the positioning abnormality of the abnormal unit 3.
- Positioning locator 4fault It sets the positioning abnormality of the abnormal unit 4.

[Button]

- Establish It establish the change contents.
- Read It displays the loading screen of Timer setting
- Write It displays the writing screen of Timer setting
- Print It runs the printing of Timer setting
- OK It is to accept the changes and return to the position setting menu.
- Cancel It erases the changes and return to the position setting menu.



Print screen: Print the current screen as it is.



Undo: Undo changes.

4-3.Nutrunner setting

When you select "Nut runner Setting" from "Setting menu", the following screen will be displayed.




Fig. (4-19):Nut runner setting

[Button]

- RATE.SET(F1)
Here, we set the rated data of the nut runner to be used.
- Block control(F2)
This displays the block setting management screen used for program setting.
- Manual setting(Parametor)(F3)
This sets each tightening motion.
- Auto setting (F4)
In this case, the tightening data required for auto setting is set, and the tightening data is automatically created based on it.
- Return to the main menu(F5)
When this button is pushed, it returns to the main menu.
- Return to the setting menu(F12)
When this button is pressed, it returns to the setting menu.

4-3-1.RATE.SET

When the screen is selected "Rating setting" from "Nut runner setting menu" it will be the screen shown below.




Fig.(4-20):RATE.SET screen

[Item]

- Rate No. You select the rated number to set.
- Nut runner type You select the type of nutrunner to use.
※If you select the Nutrunner model, the motor model and the details on the right side of the above figure become to the corresponding values.
- Motor model You select the motor model to use.
- Tightening direction This sets the direction of rotation in PRE.T and REA.T operation of the nut runner.

Details:

- Torque sensor rating (input range: 0 to 6550)
This shows the maximum torque of the nut runner to be used.
- Rating limit (input range: 0 to 3276.7)
This is a tolerance of variation during current check.
- Setting limit (Input range: 0 to 3276.7)
This is the maximum value of the allowable current output value during current check.
- CAL (Input range: 0 to 3276.7)
It is a coefficient to set so that the display value of the reference instrument and GKL monitor value are the same.
- Reduction ratio (input range: 0 to 9999)
This shows the reduction ratio of the nut runner.

[Button]

- Establish It establish the change contents.
- Read It displays the loading screen of Rate setting
- Write It displays the writing screen of Rate setting
- Print It runs the printing of Rate setting
- OK It is to accept the changes and return to the Nut runner setting menu.
- Cancel It erases the changes and return to the Nut runner setting menu.



Print screen: Print the current screen as it is.



Undo: Undo changes.



Copy: It copies the setting contents for each setting number.



Paste: It pastes the information acquired by copying to the specified setting number.

4-3-2. Block control

When you select "Block Management" from "Nut Runner Setting Menu", the following screen will be displayed.

You need to create a block to set up tightening behavior in the program and register the block to use for the axis.

Here we edit and delete that block and register on each axis.




Fig.(4-21):Block control screen

[Item]

- List of block layout This displays the blocks registered for each axis.
- List of block contents This shows the composition of the created block.

[Button]

- Delete block
This deletes the currently selected block in the block contents list.
The block to be deleted turns yellow when selected before deleting.
- Delete block layout
This deletes the block selected in the block allocation list.
When selected for each cell, the block in the currently selected cell is deleted, and when the axis number is selected, all the blocks registered on that axis are deleted.
※You can substitute Delete key and Back space key for the function of this button.
However, in that case, it can only delete per cell.
- Block layout
The created block is stored in the selected cell on the list of block layout.
This means that the block is registered to the axis number to which the stored cell belongs.
※If you enter a number directly in the selected cell on the list of block layout, the block number of that number is registered.
- Edit of block
This opens the block edit screen and edits and creates the contents of each block.

- Read It displays the loading screen of Block control.
- Write It displays the writing screen of Block control.
- Image of torque curve
This displays the waveform image screen of the selected block.
You can also change the settings on the screen that opens here.
- Program setting
When this button is pressed, you go to the program setting screen.
- O K
It is to accept the changes and return to the Nut runner setting menu.
※If you come to this screen from the program setting, you will return to the program setting screen.
- Cancel
It erases the changes and return to the Nut runner setting menu.
※If you come to this screen from the program setting, you will return to the program setting screen.

4-3-2-1.Edit of block

When you press the block edit button, the following block edit screen will be displayed.




Fig.(4-22): Edit of Block

Here, if you select the setting number from "SOC.T, PRE.T, REV.T, REA.T" list, the tightening motion is stored in the setting list on the right side of the screen. If you press the retry button, a retry command is entered, and when the end button is pressed, the end command is stored in the setting list. This setting list becomes a block.

※The insertion method of the command has difference by the cell color difference. Yellow overwrites, white inserts into the selected cell, and shifts the following commands down. The color of the cell changes by clicking.

注) The setting of each tightening operation is white as input, and purple as not yet input. If you select by right click or when you select an unentered action, it becomes yellow as currently selected, but it is not inserted in the setting list.

[Button]

- Establish

Normally it is used to confirm the change, but this function can not be used on this screen.

- RETRY

It inserts a retry command into the configuration list.

If the operation above the retry command within the block does not yield NG, the block is terminated as is, and if NG occurs, the operation below the retry is performed.

- END

It inserts an end command into the configuration information.

This command is used to make it recognize that the entire operation of the block has ended.

Even if it is not inserted in the setting information list by the command, it is automatically inserted at the end of the block when setting is completed.

- One line insertion

It inserts an empty cell in front of the currently selected cell in the setting list.

- One line delete

It deletes the currently selected cell in the setting list.

The commands lower than the delete command are moved up by the deleted command.




Fig.(4-23): Change due to "One line delete"

- Clear

It deletes all commands in the setting list.

- Change of tightening parameter

It moves to the setting screen of the operation being selected in the tightening operation list.

- O K

It is to accept the changes and return to the Block control screen.

- Cancel

It erases the changes and return to the Block control screen.

4-3-3.Manual setting

When you select "Manual setting [Parameter]" from "Nutrunner setting", the following screen will appear.




Fig.(4-24):Manual setting

[Button]

- SOC.T SET(F3)
When this button is pushed, the SOC.T SET screen is displayed.
- PRE.T SET(F4)
When this button is pushed, the PRE.T SET screen is displayed.
- REV.T SET(F5)
When this button is pushed, the REV.T SET screen is displayed.
- REA.T SET(F6)
When this button is pushed, the REA.T SET screen is displayed.
- Return to the setting menu(F12)
When this button is pushed, it will return to the Nut runner setting screen.

4-3-3-1.SOC.T SET

When you select "SOC.T SET" from "Manual setting menu (Parameter)", the following screen is displayed.
Here, we set up the operation of "SOC.T".




Fig.(4-25):SOC.T SET screen

※You can move to "PRE.T", "REV.T", "REA.T" with the button on the upper right of this screen.

[Item]

- Rotation angle It sets the operating angle during SOC.T operation.
- Speed It sets the rotation speed at SOC.T operation.
- Rotation direction
This sets the direction of rotation during this operation.
The direction set here varies to the rate setting to use.
- Change of option
By setting a check here, you can set the function in the SOC.T operation such as changing the operation type.
 - Operation
This selects the operation type of SOC.T from among the 4 below.
 - Torque determination OFF
⇒Normal operation will not be performed based on the detected torque value.
 - Fiting
⇒This function confirms that the socket has entered the screw head.
If it does not reach the detection torque value during the rotation angle, it becomes NG.
 - Gear check
⇒ That confirms the state of the gear of the nut runner.
When it reaches the detection torque value, it stops working and becomes NG.

- Detection torque
Here, we set the torque value to be used for gear check and fitting judgment.
 - Time before socket fitting
This sets the waiting time before the SOC.T operation starts
 - Over time
This sets the maximum operation time of the SOC.T operation.
If the operation does not end before this time, the operation is terminated and the NG judgment is output.。
- ※If the rotation angle is zero, it is assumed that the SOC.T operation is not set and input check is not executed.

[Button]

- Establish
It establish the change contents.
- Delete
This function returns all values of the setting No. being displayed before changing.
- Read
It displays the setup reading screen of the SOC.T setting.
- Write
It displays the setup writing screen of SOC.T setting.
- Print
It will print socket alignment settings.
Printing is done in a dedicated format.
- O K
It is to accept the changes and return to the Manual setting screen.
- Cancel
It erases the changes and return to the Manual setting screen.

 Print screen: Print the current screen as it is.

 Undo: Undo changes.

 Copy: It copies the setting contents for each setting number.

 Paste: It pastes the information acquired by copying to the specified setting number.

4-3-3-2.PRE.T SET

When you select "PRE.T SET" from "Manual setting menu (Parameter)", the following screen is displayed.
Here, we set up the operation of "PRE.T".




Fig.(4-26):PRE.T SET screen

※You can move to "SOC.T", "REV.T", "REA.T" with the button on the upper right of this screen.

[Item]

Fitting thread

This is the operation to align the screw with the screw hole.

- Turning angle
This sets the rotation angle during screw alignment operation.
- Speed
This sets the rotation speed during screw alignment operation.

Fast forwarding

This is the operation to turn the screw up to near the seating at high speed.

- Angle of fast forwarding
This sets the rotation angle during fast forward operation.
It shows the turning angle until the screw head is seated.
- Speed
This sets the rotation speed during fast forward operation.
It is almost no-load rotation until the screw head is seated.
Therefore, it sets possible high speed with the nut runner.
- Premature tightening determination torque
Normal torque does not reach during fast forward operation
which should be no load rotation.
When this set torque has passed during fast-forward operation, it is judged to be abnormal and fast-tightening NG is output.

Fit on work surface

This is an operation section from the end of fast forward to the end of PRE.T.

- Pretightening torque
This sets the target torque in the PRE.T motion.
The PRE.T operation is terminated by reaching this torque.
- Speed 1 finish torque
This sets the torque to switch from Speed 1 to Speed 2.
- Upper torque limit
This sets the torque value to be used for torque over judgment.
- Lower torque limit
This sets the torque value to be used for torque under judgment.
- Speed 1
This sets the speed until the torque sits from the end of fast forward.
- Speed 2
This sets the final speed up to the target torque of this operation.
- Over time
This sets the maximum operation time of the PRE.T operation.
If the operation does not end before this time, the operation is terminated and the NG judgment is output.
- Sampling start torque
This sets the torque to start angle measurement.
- Stole time
When the tightening torque reaches the cut torque, it is necessary to maintain the tightening torque for a certain time so that the torque does not decrease.
Here we set the holding time.

Change of option

- Time before PRE.T
This sets the wait time until this operation starts.
- Upper angle limit
This measures the tightening angle from the sampling starting torque.
If the measurement angle exceeds this setting value, angle over NG is output.
- Lower angle limit
This measures the tightening angle from the sampling starting torque.
If the measured angle does not exceed this set value, angle under NG is output.
- Monitoring time for no-torque
This sets the time when torque judgment is not made from the start of operation.

※If speed 1 and speed 2 are both zero, it is assumed that PRE.T operation is not set.
In the PRE.T SET screen, the input check is performed under the following conditions.
You can not set contrary to the input rule by input check.
However, when it is judged that it is not set, it does not perform input check.

[input condition]

- Overtime > = 1
- Fast-forward angle > = rotation angle
- Upper angle limit > Lower angle limit
- PRE.T torque > Sampling start torque
- Upper torque limit > PRE.T torque > Lower torque limit

[Button]

- Establish
It establish the change contents.
- Delete
This function returns all values of the setting No. being displayed before changing.
- Read
It displays the setup reading screen of the PRE.T setting.
- Write
It displays the setup writing screen of PRE.T setting.
- Print
It will print PRE.T settings.
Printing is done in a dedicated format.
- O K
It is to accept the changes and return to the Manual setting screen.
- Cancel
It erases the changes and return to the Manual setting screen.



Print screen: Print the current screen as it is.



Undo: Undo changes.



Copy: It copies the setting contents for each setting number.



Paste: It pastes the information acquired by copying to the specified setting number.

4-3-3-3.REV.T SET

When you select "REV.T SET" from "Manual setting ", the following screen is displayed.




Fig.(4-27):REV.T SET screen

※You can move to "SOC.T", "PRE.T", "REA.T" with the button on the upper right of this screen.

[Item]

- Judgment of torque
It sets the measurement angle so as to measure at no-load rotation.
It judges whether the torque at that time exceeds this set value or not.
- Reverse angle
This sets the movement angle in this operation.
- Speed 1
This sets the rotation speed at the start of the REV.T operation.
- Measurement angle
This sets the angle from the start of operation to judge the state of the screw using the judgment torque.
- Passing torque
It is the torque to judge whether it was tightened correctly before this operation.
If the slackening torque does not exceed this torque even once,
the NG judgment is output.
- Baking torque
Screws may be seized in the previous tightening operation.
This setting is the torque to confirm that it is baked.
- Over time
This sets the maximum operation time of the REV.T operation.
If the operation does not end before this time, the operation is terminated
and the NG judgment is output.

Option

- Speed 1 finish angle
When loosening the fastened screw with high torque, you need to loosen it
at low speed immediately after starting operation.
This setting value is the starting point for switching from low speed to high speed.

- Speed 2
When loosening the tightened screw, the no-load rotation is performed after the torque has come off.
This setting will be the speed for high-speed rotation at that time.

- Time before reverse rotation
This sets the standby time before the REV.T operation starts.

※If the Reverse angle is zero, we regard it as not set for the REV.T operation.
In the REV.T SET screen, the input check is performed under the following conditions.
However, when it is judged that it is not set, it does not perform input check.

- Over time ≥ 1
- Reverse angle \geq Measurement angle
- Reverse angle \geq Speed 1 finish angle

[Button]

- Establish
It establish the change contents.
- Delete
This function returns all values of the setting No. being displayed before changing.
- Read
It displays the setup reading screen of the REV.T setting.
- Write
It displays the setup writing screen of REV.T setting.
- Print
It will print REV.T settings.
Printing is done in a dedicated format.
- O K
It is to accept the changes and return to the Manual setting screen.
- Cancel
It erases the changes and return to the Manual setting screen.



Print screen: Print the current screen as it is.



Undo: Undo changes.



Copy: It copies the setting contents for each setting number.



Paste: It pastes the information acquired by copying to the specified setting number.

4-3-3-4.REA.T SET

When you select "REA.T SET" from "Manual setting" the following screen is displayed.

The screenshot shows a software window titled "GKL Ver.0.0.12" with a "REA.T SET" dialog box. The dialog has a title bar and a menu bar with "SOC.T", "PRE.T", "REV.T", and "REA.T" (highlighted in green). Below the menu bar are buttons for "Establish", "Delete", and "Setting No. 1". The main area contains two columns of input fields for parameters: Reatightening torque (28.0 N.m), Sampling start torque (14.0 N.m), Speed 1 (80 rpm), Speed 1 finish angle (180 °), Speed 2 (20 rpm), Over time (5 sec.), Upper torque limit (35.0 N.m), Lower torque limit (25.0 N.m), Stole time (50 msec.), and Over cutting angle (360 °). A "Change of option" section is expanded, showing fields for Time before final tightening (0 msec.), Upper angle limit (999.9 °), Lower angle limit (0.0 °), Premature tightening determination angle (0 °), Monitoring time for no-torque (0 msec.), Option mode of speed 3,4 (unchecked), Speed 3 select angle (0 °), Speed 3 (0 rpm), Speed 4 select torque (0.0 N.m), and Speed 4 (0 rpm). At the bottom are buttons for "Read", "Write", "Print", "OK", and "Cancel".

Fig.(4-28):REA.T SET screen

※You can move to "SOC.T", "PRE.T", "REV.T" with the button on the upper right of this screen.

[Item]

- Reatightening torque
This sets the target torque value in the REA.T operation.
- Sampling start torque
This sets the torque to start angle measurement.
- Speed 1
This sets the speed 1 value of the REA.T motion.
- Speed 1 finish angle
This sets the angle value to switch to Speed 2 after finishing Speed 1.
- Speed 2
This sets the rotation speed of speed 2.
- Over time
This sets the maximum operation time of the REA.T operation.
If the operation does not end before this time, the operation is terminated and the NG judgment is output.
- Upper torque limit
This sets the torque value to be used for torque over judgment.
- Lower torque limit
This sets the torque value to be used for torque under judgment.
- Stole time
When the tightening torque reaches the cut torque, it is necessary to maintain the tightening torque for a certain time so that the torque does not decrease.
Here we set the holding time.

- Over cutting angle
This sets the maximum movement angle of the REA.T motion.
When this angle is reached, this operation is terminated.

※This setting value will not output NG judgment.
If tightening condition is satisfied even a little, please note that OK judgment output.

Option

- Time before final tightening
This sets the time until the REA.T operation starts
- Upper angle limit
This measures the tightening angle from the sampling starting torque.
If the measurement angle exceeds this setting value, angle over NG is output.
- Lower angle limit
This measures the tightening angle from the sampling starting torque.
If the measured angle does not exceed this set value, angle under NG is output.
- Premature tightening determination angle
This sets the angle to be used for judging the fast-tightening abnormality.
If the final tightening torque is detected before the angle from the start of operation exceeds this set value, NG of the quick tightening will be output.
- Monitoring time for no-torque
This sets the time when torque judgment is not made from the start of operation.

Option mode of speed 3, 4

- Speed 3 select angle
This is the angle to switch to Speed 3.
- Speed 3
This sets the rotation speed of Speed 3.
- Speed 4 select torque
This sets the torque value to switch from Speed 3 to Speed 4.
- Speed 4
This sets the rotation speed of Speed 4.

※If the Reatightening torque is zero, we regard it as not set for the REA.T operation.
In the REA.T SET screen, the input check is performed under the following conditions.
However, when it is judged that it is not set, it does not perform input check.

- Overtime > = 1
- Upper angle limit > Lower angle limit
- Upper torque limit > PRE.T torque > Lower torque limit

[Button]

- Establish
It establish the change contents.
- Delete
This function returns all values of the setting No. being displayed before changing.
- Read
It displays the setup reading screen of the REA.T setting.
- Write
It displays the setup writing screen of REA.T setting.
- Print
It will print REA.T settings.
Printing is done in a dedicated format.
- O K
It is to accept the changes and return to the Manual setting screen.
- Cancel
It erases the changes and return to the Manual setting screen.



Print screen: Print the current screen as it is.



Undo: Undo changes.



Copy: It copies the setting contents for each setting number.



Paste: It pastes the information acquired by copying to the specified setting number.

4-3-4.Auto setting

When you select "Auto setting" from "Nutrunner setting", the screen shown below will be displayed.




Fig.(4-29):Auto setting screen

STEP1 :

Here, you enter basic information to perform auto setting.

Basic information refers to the rated number of NR to be used, screw tightening direction, tightening method of REA.T, target torque, upper torque limit value, lower torque limit value.

STEP2 :

"Full-auto setting" or "Setting of sampling data" is selected.

[Button]

- Cancel

It is to accept the changes and return to the Nut runner setting screen.

- NEXT

The page of the destination is different by selecting the setting method of STEP 2.

- In the case of "Full-auto setting"

When full auto setting is selected, the "Standard setting" screen is displayed. There, it inputs "screw type, distance to seated, inclusion".

- In the case of " Setting of sampling data"

When " Setting of sampling data" is selected, the " Setting of sampling data" screen is displayed.

There, it automatically performs sampling tightening and automatically performs the setting for the operation set by using the data detected from it.

4-3-4-1. Full-auto setting

If you select "Full-auto setting" in "Auto setting" and press "NEXT", the "Standard setting" screen shown below will be displayed.




Fig.(4-30):Full-auto setting(Standard setting)screen

※Refer to "9-3. Preparation of tightening program" for setting flow chart.

[Item]

- Rate No.
The rated number of the nut runner set on the "Full-auto setting" screen is displayed.
- Axis No.
It selects axis number.
It assigns the block you created to this axis.
- Kind of thread
It selects the type of screw.
- Bolt seat is fit on work surface
It chooses whether the bolt is seated or not.
If it is seated, the only items you set are inclusions.
In case of non-seating, it is necessary to set the distance(angle) to sit in addition to that.
- Gap of bolt
It sets the distance between the screw head and the workpiece seat.
- Pitch of thread
It sets the screw pitch.
- Revolving number of times until fit on work surface
It sets the number of revolutions until sitting.
- Inclusion
It selects inclusions to enter between the screw and the seat.

[Button]

- Cancel
It erases the changes and return to the Manual setting screen.
- Back
It erases the changes and return to the previous setting screen.
- Next
It creates a block and its behavior from this screen and the data set on the previous screen.
Then, the created block is displayed as a waveform image.

When you select "Next" on the "Standard setting" screen, the "Screen for image of torque curve" as shown below will be displayed.




Fig.(4-31):Screen for image of torque curve

In this screen, you can change the behavior of the block created based on the previous setting while confirming it as a waveform.

※Please check the setting items of each operation about the contents of detailed setting.

[Button]

- Read
This is the same operation as " Setting read" in the main menu.
- Write
This is the same operation as " Setting write" in the main menu.
- Graph checking
When this button is pushed, a simple waveform that reflects the set contents will be displayed.
- OK
This holds the created block and each action and displays it on the Nut runner setting screen.
- Cancel
This discards the created block and each action and returns to the previous screen.

4-3-4-2. Setting of sampling data

When you select " Setting of sampling data " with "Auto setting" and press "NEXT", "SAMPLING SETTING" is displayed.




Fig.(4-32): Setting of sampling data

※Please check the setting items of each operation about the contents of detailed setting.

①The angle until the taking a seat is gauged with a low-speed revolving try. Please choose movement axis number and set it in the state until a bolt is tightened up. Please press a low-speed revolving try button including driving preparations at the tightening starting position. The angle until the taking a seat of a screw is measured by pressing a low-speed revolving try button. After that it revolves by the speed of the 40RPM, and when I reach "the tightening sampling stop torque", stops. The degree of general rotation angle from a start to the stop of that case is measured. About 1.5 times more than the degree of rotation angle measured after tightening is reversed and the movement which slackens a screw is performed, and it's a movement end. During moving, following message goes out.



Fig.(4-33): During low speed rotation try

- ※1: Please establish the "tightening sampling stop torque" of the controller before a low-speed revolving try. It's 0, so if it's just as it is, defaults don't circulate at low speed.
 - ※2: When or the operation time exceeds 60 seconds when not reaching "tightening sampling stop torque" even if it revolves 9999 times during a try, a controller takes out an alarm "E33".
- ②The data for which setting is made with a measurement starting button is acquired. When a step is chosen by movement choice and a measurement starting button is pressed, the setting value and the program originated with the data a low-speed revolving try gave are sent to the controller. Please carry out the following program number by a PLC after a measurement starting button is pressed.

※The program made with a low-speed revolving try is preserved by the last program number.

The number of program changes with the program Max value choice in the following.

30axis, 16program, 220steps ⇒ program number : 16

30axis, 50program, 70steps ⇒ program number : 50

8axis, 50program, 220steps ⇒ program number : 50

The setting made with a low-speed revolving try starts to be the next.

Socket adjusting is 47-49, pre-tightening is 50 reverse rotation is 50 and final tightening is 50.

During beginning to measure, following message goes out.

Only that it's necessary, please execute a program.

If data is acquired, it "now sampling", please press a cancellation button of the window of a message.



Fig.(4-34): Now on sampling

③If I finish acquiring data as much as it's necessary by measurement starting, a cancellation button is pressed.

When making the set value with acquired data, excluded data is chosen by "NG" and the data acquired by a "sampling data, shifting" button after that is preserved in the setting PC.

When you'd like to set setting in a block, a in-depth setting data shift button is pressed.(To④)

When you'd like to gauge with the set value which was made with acquired data, a measurement starting button is usually pressed. (To ②)

The screen upper right develops and is corrugated.

④It's to press an in-depth setting data shift button, moves to a corrugated image screen and indicates a block of the made set value.

Information on the block is preserved by a setting PC by pushing OK.

※The made block number is the first block number which isn't being used.

It's also possible by screen for image of torque to change the set value.

4-4. Program setting

You select "Program Setting" from "Setting Menu".
 When "Program Setting" is selected from "Setting Menu",
 "Select of maximum program number" screen will appear.




Fig.(4-35): Select of maximum program number

By default, "30 axes, 16 program No., 220 steps" is selected.

If you change the program Max value selection, you will need to recreate the program.




Fig.(4-36):Program setting

[Item]

- IN
It enables 'IN signal wait'.
It waits for this step to start until the IN signal is input from the outside.
- OUT
It outputs "OUT" signal after the operation is completed.
The "OUT" signal is stopped by input of the next "IN" signal.
- PRINT
After step execution, it will print the contents specified for the connected printer.
- (Program area)
The contents of the selected program number are displayed.
- ZERO
We will do zero check.
- SYNC-S
It synchronizes with other axes at the start of this step.
- SYNC-E
It will retighten at the end of this step.

4-4-1. Tightening block operation select

In "Program setting", select the block to be inserted in the program on the "Tightening block operation select " screen.




Fig.(4-37): "Tightening block operation select " screen

[Item]

- Axis No. It displays the axis number where the tightening block is inserted.
- Rate No. This specifies the rating number of the nut runner to be used for the operation of the tightening block to be selected.
- Screw No. This specifies the screw number to be tightened with the tightening block.
- Block No. This specifies the number of the tightening block to be inserted.
- → This inserts the currently selected block information into the program.
- ZERO/GAIN Check
Before starting the block operation, it checks zero times the check function of the torque sensor.
- START SYNC It is to synchronize the steps next to each other.
It is effective only when there is positioning in the unit.
※If there is no positioning inside the unit, synchronize without setting it.
- All axes start synchronous
This enables start synchronization for all axes in the program.
※It can be confirmed that start synchronization is entered on all axes in the program.
- END SYNC We will retighten after REA.T action.※REA.T step is effective only.
- All axes end synchronous
This enables all axis end synchronization for all axes in the program.
※You can confirm that the end synchronization is entered on all axes in the program.
- All axes retry synchronous
This function is effective only when Retry is selected in Block.
※when all-axis retry is set, if there is NG even for 1 axis, all-axis retry processing will be done.
- OK
This enables the setting on this screen and returns to the program setting screen.
- Cancel
This discards the setting on this screen and returns to the program setting screen.

4-4-2. X,Y axis operation select

The following screen is displayed with "XY axis operation select" button from the setting screen.

You can select the XY action you want to set from the command and insert it into the program.




Fig.(4-38): " X,Y axis operation select " screen

[Item]

- X rare. No. This sets the X axis rated number of the same unit as the setting axis.
- Y rare. No. This sets the Y axis rated number of the same unit as the setting axis.
- Point No. This sets the point number where the destination coordinates are registered.

[Button]

- One line insertion This inserts one empty cell above the selected cell in the setting list column.
- One line delete This deletes the cell selected by the setting list and fills it up.
- Clear This clears all contents of the setting list column.
- O K This will insert the contents of the setting list column into the program step and return to the program setting screen.
- Cancel This discards the contents of the setting list field and returns to the program setting.

[Command]

- MOVX This will move the X axis motor to the specified point.
- MOVY This will move the Y axis motor to the specified point.
- MOVXY This will move the X and Y axis motors to the specified point at the same time.
- WAIT①, WAIT② This waits without advancing to the next step until the WAIT input signal corresponding to each command is entered.
- SPW If you enter SPW command for all axis step number, it becomes usable.
All axes become steps of this command and wait without proceeding to the next step until the SPW signal is input.
- INX①, INX② This waits without advancing to the next step until the INX input signal corresponding to each command is entered.
- INY①, INY② This waits without advancing to the next step until the INY input signal corresponding to each command is entered.
- TIME10~10000 This command stops the operation for the number of minutes of the command.
The unit is msec.
It will proceed to the next step after the specified time has elapsed.
- SYLINDER 1 ADVANCE
It can be used when the input signal at the cylinder return end is input.
It outputs a cylinder motion signal and moves the cylinder.
It goes to the next step at the input of the signal at the cylinder working end.
- SYLINDER 1 RETURN
It can be used when an input signal at the cylinder operation end is input.
It outputs a cylinder return signal and moves the cylinder.
It will proceed to the next step at the input of the signal at the cylinder return end.
- PULSE
The operation of the cylinder continues until the end signal is input.
This command is used to protect the cylinder by forcibly turning OFF when the cylinder operation continues for a certain time.
- SYLINDER RELATIVE RETURN
This command can be used only when using a special driver for positioning.
It will rise at cylinder return to the position of Z axis rated return amount and move to the next point.

4-5. About reading and writing setting of each setting screen

"Rate, SOC.T, PRE.T, REV.T, REA.T, block, Block control , screw No., cylinder name, X rate, Y rate, Timer, Program, Unit, tightening data output, option" in the Setting menu, the setting reading of each setting screen and the setting writing are shown below. For "Cylinder name, monitoring timer, unit, tightening data output, option" there is no setting number so selection reading and selection writing of setting can not be done.

4-5-1. Each setting read

You read the settings from a file or a controller.




Fig.(4-39):Setting read screen

[Item]

• ALL

This sets all objects to be read.
"Item name ()" varies depending on the setting to be read.

• Select

It selects the number of settings to load.
By specifying "Select", you can select the list BOX of each setting.
In this selective reading, it clicks on an arbitrary number and it becomes selected and the color changes.
Multiple numbers can also be selected.

[Button]

- FILE(F1)

It reads each setting from the file.

When "All" is selected, setting of all numbers is read, and when "Selection" is selected, only the setting of the number being selected is read from the file of the extension of each setting.

- CONTROLLER(F2)

This loads each setting from the GKL controller.

When it reads the setting from the GKL controller, it is necessary that the GKL controller and the PC are connected with the USB cable.

A communication error occurs when the controller and PC are not connected.




Fig.(4-40):Communication error

- RETURN(F12)

It returns to each setting screen.

①File

In the file processing, HDD (hard disk drive) or, over the file on the other accessible media, we read each setting information. Configuration files are saved with the file extension of each setting.

Rate : GKL T, SOC.T : GKLR, PRE.T : GK LK, REV.T : GKLG, REA.T : GK LH,
Screw No. : GK LJ, Block control : GK LB, Cylinder name : GK LCN,
X rate : GK LX T, Y rate : GK LY TP, Timer setting : GK LST, Unit : GK LU,
Tightening data output : GK LOT, Option : GK LOP

In the selection of reading files, please select the file extension of each setting.




Fig.(4-41): Select reading file

It uses the file selection dialog, select the settings file to be loaded. When the reading of each configuration file is complete, the following message is displayed.




Fig.(4-42): Read complete message

②Controller

It will read each setting from GKL controller.

If you read the configuration file from the GKL controller, the controller and computer must be connected by a USB cable.

Communication error occurs when not connected.



Fig.(4-43):Communication error




Fig.(4-44): Progress status of controller reading

When the reading from the controller is finished, the following message appears.




Fig.(4-45): Controller read complete message

③ Reading selection of each setting

If you want to read the specification of the set only, choose a selection option.

Please select the specified setting because list BOX will be selected.

When you press the file button, you read only the specified settings from the file.

When you press the controller buttons, you read only the specified settings from GKL controller.

※ Since there is no set number for cylinder name and timer setting and unit and tightening data output and option, you cannot read only the specified settings.




Fig.(4-46): Select setting read

4-5-2. Each setting write

It will write the settings file, or, to the controller.




Fig.(4-47): Setting write screen

[Item]

- ALL

It sets all objects to be written.

"Item name ()" depends on the setting to be written.

- Select

It selects the number of the setting to be written.

If you select selection, you can select the list BOX of each setting.

In this selective writing, clicking an arbitrary number changes it as selected and the color changes.

Multiple numbers can also be selected.

[Button]

- FILE(F1)

It writes the settings from the file.

- CONTROLLER(F2)

It will write each setting from GKL controller.

If you write the configuration file from the GKL controller, the controller and computer must be connected by a USB cable.

Communication error occurs when not connected.




Fig.(4-48):Communication error

- RETURN(F12)

It returns to each setting screen.

①File

In "File", it writes each setting information to HDD (hard disk drive) or other file on accessible media.

The setting file that saves each setting information is automatically selected in the write dialog.




Fig.(4-49): Writing file named

You will use the file selection dialog, and name to write the configuration file. When the writing of the configuration file is complete, the following message is displayed.




Fig.(4-50):Writing complete message

②Controller

It will write each setting from GKL controller.

If you write the configuration file from the GKL controller, the controller and computer must be connected by a USB cable.

Communication error occurs when not connected.

The password to write to the controller is required. (Initial Password: 2014)

If the password is unknown, the configuration file cannot be written to the controller.




Fig.(4-51):Communication error




Fig.(4-52):Password check

Please turn OFF the operation preparation.

It cannot be written the configuration file when you don't turn OFF the operation ready.




Fig.(4-53):Operation ready OFF confirmation

When writing to the controller is finished, the following message appears.




Fig.(4-54):Writing complete message to controller

③ Writing selection of each setting

If you want to write the specification of the set only, choose a selection option. Please select the specified setting because list BOX will be selected.

When you press the file button, you write only the specified settings to the file. When you press the controller buttons, you write only the specified settings to GKL controller.

※ Since there is no set number for the cylinder name and timer setting and the unit and the data output and the option, you cannot write only the specified settings.




Fig.(4-55): Select setting write

5.Auto measurement

When you select "Auto measurement" from "main menu" the following screen will be displayed.




Fig.(5-1):Auto measurement screen

[Button]

- Online(F1) In this item it is possible to obtain and check the result data each time the tightening ends. It can also be saved by selection.
- Tightening wave(F2) In this item, you can check and save the tightening waveform of each axis.
- Tightening record(F3) In this item you can see the record of the tightening result saved in the controller.
- Alarm history(F4) In this item you can see the history of alarms saved in the controller.
- Cycle monitor(F5) In this item you can monitor the signals exchanged between the PLC and the controller.
- Display of current step(F6) In this item, you can check the operation which is executed by the equipment from the program table.
- Return to the main menu(F12) We can return to th main menu.

5-1. Online

When you select "Online" from "Automatic measurement screen", the following screen will appear.

In this item, the tightening result is received from the controller and displayed at the end of block.

Advs No.	Screw No.	Date	Time	P.No.	U.No.	Determination	Sokat setting		Pretightening			Reverse rotation		Final tightening		WorkNo.
							Torque	Fast Read torque	Torque	Angle	Time (0.0msec)	Torque	Angle	Time (0.0msec)	Sampling start torque	
1	1	18/11/13	1654:05	1	1	O	23	2.2	5.0	3.6	590	1.3	7.4	7.6	66	3.5 ⁰
2	2	18/11/13	1654:05	1	1	O	23	2.1	4.9	4.1	524	1.0	7.4	7.0	65	3.5 ⁰
3	3	18/11/13	1654:05	1	1	O	25	2.2	4.9	10.5	515	1.4	7.4	15.1	68	3.5 ⁰
4	4	18/11/13	1654:05	1	1	O	23	2.2	4.9	7.4	527	1.2	7.4	7.6	65	3.5 ⁰
5	5	18/11/13	1654:05	1	1	O	25	2.2	5.0	8.7	517	1.7	7.4	8.6	65	3.5 ⁰
6	6	18/11/13	1654:05	1	1	O	23	1.9	4.9	4.5	513	1.0	7.4	7.7	66	3.5 ⁰
7	7	18/11/13	1654:05	1	1	O	27	2.2	5.0	4.7	535	1.3	7.4	7.6	65	3.5 ⁰
8	8	18/11/13	1654:05	1	1	O	23	2.1	5.0	6.7	515	1.0	7.4	8.5	65	3.5 ⁰
9	9	18/11/13	1654:05	1	1	O	23	2.1	5.0	9.3	515	1.0	7.4	11.8	66	3.5 ⁰
10	10	18/11/13	1654:05	1	1	O	22	1.9	5.0	9.0	527	1.1	7.4	10.2	67	3.5 ⁰
11	11	18/11/13	1654:05	1	1	O	23	2.1	4.9	1.4	600	1.2	7.4	4.5	64	3.5 ⁰
12	12	18/11/13	1654:05	1	1	O	24	2.4	5.0	7.2	588	1.7	7.4	8.1	66	3.5 ⁰
13	13	18/11/13	1654:05	1	1	O	21	2.1	5.0	10.0	602	1.2	7.5	20.0	73	3.5 ⁰
14	14	18/11/13	1654:05	1	1	O	1.8	1.6	5.0	11.0	601	0.8	7.5	20.8	72	3.5 ⁰
15	15	18/11/13	1654:05	1	1	O	2.2	2.0	5.0	14.5	666	1.0	7.4	25.2	79	3.5 ⁰
16	16	18/11/13	1654:05	1	1	O	2.1	1.8	5.0	11.4	665	0.7	7.4	18.1	73	3.5 ⁰
17	17	18/11/13	1654:05	1	1	O	2.3	2.0	5.0	7.4	662	1.1	7.5	20.2	74	3.5 ⁰
18	18	18/11/13	1654:05	1	1	O	1.8	1.5	4.9	10.1	605	1.4	7.5	19.9	71	3.5 ⁰
19	19	18/11/13	1654:45	1	1	O	0.0	0.0	0.0	0.0	0	0.0	7.5	1.2	51	3.5 ⁰
20	20	18/11/13	1654:45	1	1	O	0.0	0.0	0.0	0.0	0	0.0	7.5	1.5	20	3.5 ⁰

Fig.(5-2):Online screen

GKL Ver.0.0.12

Do you want to communicate?

Online data is saved at a file.

YES NO

Fig.(5-3):Communication check

If you want to automatically save the tightening result, please check "Save online to file".

The result saved in this "online" is the result of each operation for 1 tightening. If duplicate actions are found within the tightening block, the result of the last executed action is saved.

※As an example, if there is a tightening block of "SOC.T 1 → PRE.T 1 → PRE.T 2 → REV.T 1 → REA.T 2 → REA.T 3", the saved result is "SOC.T 1 → PRE.T 2 → REV.T 1 → REA.T 3".

※The tightening result of the online item is saved in "C: ¥ GIKEN ¥ GKL setting ¥ automatic measurement ¥ Online".

[Item]

- Axis No. It displays the axis No. that executed the tightening.
- ScrewNo. The tightened screw No. is displayed.
- Date This will display the date at the end of the tightening.
- Time This displays the time at the end of the tightening.
- P No. Here, the program No. used for tightening is displayed.
- U No. The unit number to which the tightened shaft belongs is displayed.
- Ditermination If this item is OK, ○ is displayed, and if it is NG, NG code is displayed.
- SOC.T
 - Torque The torque value at the end of "SOC.T" is displayed. The unit is Nm.
- PRE.T
 - Fast feed torque
When NR reaches the fastening angle, the maximum torque value within the fast feed section is displayed.
The unit is Nm.
If NR does not turn to the fastening angle, 0 Nm will be displayed.
 - Torque The torque value at the end of the PRE.T operation is displayed. The unit is Nm.
 - Angle Here, the angle from the sampling start torque is displayed.
 - Time Here, the time since the PRE.T start is displayed. The unit is 10 msec.
- REV.T
 - Torque The torque value at the end of the REV.T operation is displayed.
- REA.T
 - Torque The torque value at the end of the REA.T operation is displayed. The unit is Nm.
 - Angle The angle from the sampling start torque is displayed in the unit of "°".
 - Time The time from the start of REA.T is displayed in units of 10 msec.
 - Sampling start torque The angular measurement starting torque of Rea.T is displayed in the unit "Nm".
- Work No. The classification number to be tightened is displayed when that information is received.

[Button]

- Return to the Auto measurement menu
You can return to the automatic measurement menu.

5-2.Tightening wave

When you select "Tightening waveform" from "Automatic measurement screen" the following figure is displayed.

In this screen you can display or save the tightening waveform.




Fig.(5-4):Communication check

The behavior of this item changes with the answer to the first "do you want to communicate?"

In case of "Yes"

Automatically displays the tightening waveform ("time – torque and speed", "angle – torque and speed", elongation waveform) each time the tightening block ends. Switching the display axes is done by selecting the axis No. at the top of the screen. When "Save waveform data" is selected, the waveform information is automatically saved in a file.

In case of "No"

If you select "No", you can manually read the tightening waveform ("time – torque and speed", "angle – torque and speed", elongation waveform) from the controller.

The loaded waveform data can be saved to a file manually.

In addition, you can read the saved waveform data file and display the waveform.

※The file of tightening waveform information is saved in "C: ¥ GIKEN ¥ GKL setting ¥ automatic measurement ¥ waveform".

In case of checking automatic saving of tightening waveform

It is necessary to set the OK range for each program displayed as a waveform.
※The part specified in the OK range is surrounded by a red frame in the graph.
When setting the OK range is completed, it operates
in the automatic display mode and communicates with the controller.




Fig.(5-5): Set OK range

[Item]

- PROGRAM No. This indicates the program number for setting "OK range".
- Upper torque limit This sets the upper torque limit of the OK range.
- Lower torque limit This sets the lower torque limit of the OK range.
- Upper angle limit This sets the upper angle limit of the OK range.
- Lower angle limit This sets the lower angle limit of the OK range.
- Work name You can fill in the work name and notes.

[Button]

- OK It saves the settings and moves to the auto collection screen.
- Cancel This will move to the automatic collection screen without setting it.




Fig.(5-6): Automatic waveform acquisition mode

[Item]

- (Wave type※) It is fixed to the waveform of preselected type.
※This item name is not listed on the screen.
- AXIS No. This selects the axis number for displaying the waveform. When "All axes" is selected, graphs of all axes overlap and they are displayed. Also, if you select each axis number, a graph of each axis will be displayed.
- Waveform data making It displays the date and time when the tightening waveform information was acquired.
- PROGRAM No. The program No. that acquired the tightening waveform information is displayed.
- SCREW No. This shows the screw number from which the tightening waveform information was acquired.
- Work name This item displays the work name and attention etc. indicated at setting the "OK range".
- (Detailed data display※) It is located on the right side of the screen and displays the following values for each screw number.
- COLOR The waveform of the corresponding screw number is displayed in this color.
- TRQ This will display the result torque.
- SNAG This shows the resulting snug torque (sampling start torque).
- ANGLE This displays the result angle.
- Total determination This judgment result of 1 tightening will be displayed.
- Graph It displays a graph corresponding to each axis (color of detailed data). The speed waveform is indicated by the dotted line, and the torque waveform is indicated by the solid line.

[Button]

- Checkbox

- Torque

When this is checked, the torque waveform is displayed in the graph area.

- Speed

When this is checked, the speed waveform is displayed in the graph area.

- Zoom clear

This button returns the graph enlarged with the mouse to the original graph.

- Print the screen

This button prints the currently displayed screen.

- Return to the Auto measurement menu

You can return to the automatic measurement menu.



Print the screen : This button prints the currently displayed screen.

In case of tightening waveform manual save mode (When "No" is selected)




Fig.(5-6): Tightening waveform screen

※The red line shows the torque graph and the blue line shows the speed graph. Dragging the graph will enlarge the range.

- (Wave type※) In this item, you select the type of tightening waveform to be displayed on the graph from three types (time - torque and speed, angle - torque and speed, extension waveform)
 ※This item name is not listed on the screen.

[Item]

- AXIS No. This selects the axis number for displaying the waveform.
- Waveform data making It displays the date and time when the tightening waveform information was acquired.
- PROGRAM No. The program No. that acquired the tightening waveform information is displayed.
- SCREW No. This shows the screw number from which the tightening waveform information was acquired.
- TIGHTENING RESULT
 - Total determination This judgment result of 1 tightening will be displayed.
 - TORQUE If the final operation is REA.T or PRE.T, the final torque value is displayed in the unit Nm. For other operations, 0 is displayed.
 - ANGLE When the final motion is REA.T or PRE.T, the angle from the sampling start torque is displayed in °. For other operations, 0 is displayed.
 - Sampling start torque When the final operation is REA.T or PRE.T, the angle measurement start torque value is displayed. For other operations, 0 is displayed.
 - TIME When the final motion is REA.T or PRE.T, the angle from the sampling start torque is displayed. For other operations, 0 is displayed.

- (Detailed data display※) It is located on the right side of the screen and displays the following values for each item. By selecting the data in the table with the mouse and pressing the graph creation button, you can create a waveform in an arbitrary data range.
- TRQ The torque value acquired for each sampling from the start of tightening is displayed.
- TIME This shows the time when sampling was started from the start of tightening to the end.
- ANGLE The angle value acquired for each sampling from the start of tightening is displayed.
- SPEED The speed value acquired for each sampling from the start of tightening is displayed. (This unit is "rpm".)
- Graph It displays a graph corresponding to the axis. (This axis number is selected in the "axis number" item.)

[Button]

- Checkbox
 - Torque When this is checked, the torque waveform is displayed in the graph area.
 - Speed When this is checked, the speed waveform is displayed in the graph area.
- Zoom clear This button returns the graph enlarged with the mouse to the original graph.
- Graph creation This creates a waveform from the information being selected from the detailed data list.
- READ Specified axis No. Read the waveform data from the controller. It also reads the waveform data from the saved file.
- Save data This saves the waveform data read from GKL in a file.
- Print the screen This button prints the currently displayed screen.
- Return to the Auto measurement menu You can return to the automatic measurement menu.



Print the screen : This button prints the currently displayed screen.

5-3.Tightening record

When you select "tightening history" from "automatic measurement menu", it will change to the screen shown below.

In this case, you can acquire and display the tightening record information from the controller.

In this screen you can also save the displayed tightening history in a file.

SCREW No.	Date	Time	P.No.	U.No.	TQ	Angle	Time	Snag	Determination	NG Processing	DATA No.
1	18/10/23	10:35	1	1	7.4	176.0	64	3.5	○		844200
2	18/10/23	10:35	1	1	7.4	141	85	3.5	○		844200
3	18/10/23	10:35	1	1	7.4	15.0	64	3.5	○		844200
4	18/10/23	10:35	1	1	7.4	179.9	68	3.5	○		844200
5	18/10/23	10:35	1	1	7.5	17.5	68	3.5	○		844200
6	18/10/23	10:35	1	1	7.5	17.9	71	3.5	○		844200
7	18/10/23	10:35	1	1	7.5	21.3	88	3.5	○		844200
8	18/10/23	10:35	1	1	7.4	16.1	88	3.5	○		844200
9	18/10/23	10:35	1	1	7.5	20.4	67	3.5	○		844200
10	18/10/23	10:35	1	1	7.5	189.4	74	3.5	○		844200
11	18/10/23	10:35	1	1	7.4	19.4	65	3.5	○		844200
12	18/10/23	10:35	1	1	7.4	16.6	85	3.5	○		844200
13	18/10/23	10:35	1	1	7.4	10.6	93	3.5	○		844200
14	18/10/23	10:35	1	1	7.4	5.8	64	3.5	○		844200
15	18/10/23	10:35	1	1	7.4	5.7	64	3.5	○		844200
16	18/10/23	10:35	1	1	7.4	8.3	65	3.5	○		844200
17	18/10/23	10:35	1	1	7.4	11.3	85	3.5	○		844200
18	18/10/23	10:35	1	1	7.5	68.5	68	3.5	○		844200
19	18/10/23	10:43	1	1	7.4	174.5	64	3.5	○		844200
20	18/10/23	10:43	1	1	7.4	15.2	66	3.5	○		844200
21	18/10/23	10:43	1	1	7.4	6.7	85	3.5	○		844200
22	18/10/23	10:43	1	1	7.4	179.0	64	3.5	○		844200
23	18/10/23	10:43	1	1	7.5	20.9	71	3.5	○		844200
24	18/10/23	10:43	1	1	7.5	16.8	71	3.5	○		844200
25	18/10/23	10:43	1	1	7.4	185.8	75	3.5	○		844200
26	18/10/23	10:43	1	1	7.4	18.8	88	3.5	○		844200
27	18/10/23	10:43	1	1	7.5	178.0	70	3.5	○		844200
28	18/10/23	10:43	1	1	7.4	196.2	81	3.5	○		844200
29	18/10/23	10:43	1	1	7.4	175.5	64	3.5	○		844200
30	18/10/23	10:43	1	1	7.4	13.1	65	3.5	○		844200
31	18/10/23	10:43	1	1	7.4	20.1	88	3.5	○		844200
32	18/10/23	10:43	1	1	7.4	16.9	83	3.5	○		844200
33	18/10/23	10:43	1	1	7.5	5.5	64	3.5	○		844200
34	18/10/23	10:43	1	1	7.5	5.5	64	3.5	○		844200
35	18/10/23	10:43	1	1	7.5	7.3	64	3.5	○		844200
36	18/10/23	10:43	1	1	7.4	88.8	85	3.5	○		844200
37	18/10/23	10:48	1	1	7.4	10.6	64	3.5	○		844200
38	18/10/23	10:48	1	1	2.7	0.1	1500	0.0	0233 : PreTiph	NO	844200
39	18/10/23	10:48	1	1	7.4	4.8	64	3.5	○		844200
40	18/10/23	10:48	1	1	7.4	182.4	67	3.5	○		844200
41	18/10/23	10:48	1	1	7.5	23.1	70	3.5	○		844200
42	18/10/23	10:48	1	1	7.5	19.0	73	3.5	○		844200
43	18/10/23	10:48	1	1	7.4	22.6	72	3.5	○		844200
44	18/10/23	10:48	1	1	7.4	21.0	70	3.5	○		844200

Fig.(5-8):Tightening record

[Item]

- SCREW No. It displays the screw number.
 - Date It displays the date when the tightening of the target data was completed.
 - Time It displays the hour and minute when the tightening of the target data is completed.
 - P.No. It displays the program No. used for the target data.
 - U.No. It displays the unit number of the target data.
 - TQ It displays the torque result of the target data. (Unit: Nm)
 - Angle It displays the angular result of the final action of the target data. (Unit: °)
 - Time It displays the time result of the target data. For this time result the thing of the final operation is used. (Unit: msec)
- ※If the final operation is PRE.T, REA.T, it is the same as the value of online temporary tightening and final tightening.
- Snag It displays angle measurement start torque value.

- Determination When the judgment is OK, ○ is displayed.
And when it is NG, the NG code is displayed.
- NG Processing It shows whether there was NG processing by QL input.
If there is QL processing, it displays "presence".
Others it displays "absence"

※When using the positioning mode, it is not saved in the tightening record regardless of whether QL processing is performed or not.

- DATA No. It displays the engine number of the workpiece
that was tightened.

※The order of the data is obtained from the controller and rearranged in the order of date, time and screw number.

[Button]

- AXIS No.. You select axis numbers to read from all axes and each axis.
- READ It will read the tightening record of the selected axis number.
- CANCEL You can cancel reading by pressing during loading.
- Record clear It clears the tightening history information stored in the controller.
- Record write It saves the displayed tightening record in a CSV format file.
- Return to the Auto measurement menu
You can return to the automatic measurement menu.

5-4. Alarm history

When you select "Alarm history" from "Automatic measurement", the following screen will appear.

You can acquire alarm history information from the controller and save the displayed alarm history to a file.




Fig.(5-9):Alarm history

[Item]

- Axis No. The axis number where the alarm occurred is displayed.
- Date It displays the year, month, and day when the alarm occurred.
- Time It displays the time when the alarm occurred.
- Alarm code The alarm code and contents of the occurred alarm are displayed.

[Button]

- History clear It clears the alarm history saved in the controller.
- History write It saves the displayed alarm history in a CSV format file.
- Return to the auto measurement menu You can return to the automatic measurement menu.

5-5.Cycle monitor

You will see this screen when you select "Cycle monitor" from "Automatic measurement".

This function shows the operation status of the input / output signal the controller is exchanging with PLC etc.

Also, you can save the displayed data.




Fig.(5-10):Cycle monitor

[Button]

- Data read It reads previously collected signal and its waveform from the file.
- Data write It saves the information of the displayed signal in a file.
- Setting read It reads the previously selected signal from the file.
- Setting write It selects signals to collect data and it saves the list to a file.
- Object select On the left screen of Figure 5-9, you select the name of the signal that you want to get data.
- Collect start It takes the waveform of the selected signal.
※It is the waveform after pressing the button.
- Print This prints the current screen.
- Exit It will exit this screen and return to the automatic measurement menu.

6. Quality control

When you select "Quality Control" from "Main Menu", it will be the following screen.





Fig.(6-1): Quality control menu

[Button]

- Gear check result(F1) We are planning to display the results of the gear check, but we can not use it now.
- Self diagnosis(F2) This shows the version of PC, IF unit, controller, display. It checks whether the controller versions are all the same.
- Return to the main menu (F12) You can return to the main menu.

6-1. Gear check result

When you select "Gear check result" on "Quality control menu" screen, this screen will be displayed.



The screenshot shows a window titled "GKL Ver0.0.12" with a sub-header "Gear check result". Below this is a section labeled "GEAR DISPLAY" containing a table with 30 rows and 8 columns. The columns are grouped into three pairs: (MEASUREMENT VALUE, SETTING VALUE) for axes 1-10, 11-20, and 21-30. All measurement and setting values are 0.0. A button in the bottom right corner is labeled "Returns to the quality control menu".

	MEASUREMENT VALUE	SETTING VALUE		MEASUREMENT VALUE	SETTING VALUE		MEASUREMENT VALUE	SETTING VALUE
AXIS No.1	0.0	0.0	AXIS No.11	0.0	0.0	AXIS No.21		
AXIS No.2	0.0	0.0	AXIS No.12	0.0	0.0	AXIS No.22		
AXIS No.3	0.0	0.0	AXIS No.13	0.0	0.0	AXIS No.23		
AXIS No.4	0.0	0.0	AXIS No.14	0.0	0.0	AXIS No.24		
AXIS No.5	0.0	0.0	AXIS No.15	0.0	0.0	AXIS No.25		
AXIS No.6	0.0	0.0	AXIS No.16	0.0	0.0	AXIS No.26		
AXIS No.7	0.0	0.0	AXIS No.17	0.0	0.0	AXIS No.27		
AXIS No.8	0.0	0.0	AXIS No.18	0.0	0.0	AXIS No.28		
AXIS No.9	0.0	0.0	AXIS No.19			AXIS No.29		
AXIS No.10	0.0	0.0	AXIS No.20			AXIS No.30		

Fig.(6-2): Gear check result

[Button]

- Return to the Quality control menu You can return to the "Quality control menu".

※Please note that this screen is not currently available.

6-2.Self diagnosis

When you select "Self-diagnosis" from "Quality control menu", it becomes the following screen.

It display version of the personal computer and the IF unit and the controller and the display.

And the controller version is checked that everything is same.




Fig.(6-3): Self diagnosis

[Item]

- Setting personal computer It shows the version of the setting personal computer.
 - Interface It shows the version of the Interface.
 - Driver controller It shows the version of the driver controller.
- ※If it does not match the driver version of the GKL.ini file, "ROM Ver error" is displayed.
- Display It shows the version of the display.

[Button]

- Return to the Quality control menu You can return to the "Quality control menu".

7. Print/Excel output

If you select "Print / Excel output" from "Main Menu", the following screen will be displayed.




Fig.(7-1):Print display

In "Print / Excel output", you can perform the print setting to use the printer. Also you can print and convert to Excel file of each setting.

In "ONLine printing", it is necessary to connect the printer to the interface, and in "PC setting printing", the setting PC and the interface must be connected.

[Item]

- Perform online print setting of controller data
We will select the timing to send the tightening result to the printer connected to the interface and the tightening operation to send the result.
- PC setting print
It prints data of each setting and converts the print data to Excel file.

[Button]

- Return to the main menu You can return to the main menu.

7-1. Perform online print setting of controller data

Here, we will set the printing of the tightening result.

In order to use this function, the printer must be connected to the interface.

- Print mode select It sets the timing of the automatic printing in the print mode selection. Please select from the following items.
- No automatic print Automatic printing is not performed.
- Every tightening end time Each tightening result is printed each time tightening ends.
- NG occurrence The tightening result is printed only when NG occurs.
- First N set + Data when NG occurrence
Each time the equipment is started up and set, every time the tightening ends, only when printing of the set number of copies ends, it prints only when NG occurs.

※If you select anything other than "No automatic print", select the printing operation. For this selection, you select from the following items.

- Socket fitting result print
- Pretightening result print
- Reverse rotation result print
- Real tightening result print
- Zero magnification result print

※When " First N set + Data when NG occurrence " is selected, set the first number.

※When "No automatic print" is selected, result print selection and initial number setting are not displayed.

After selecting the printing operation, press the "Setting" button, the setting of the selected printing is written to the controller.

7-2.PC setting print

- Print preview of SOC.T PRE.T REV.T REA.T
It displays the print preview screen of SOC.T, PRE.T, REV.T, and REA.T currently held on the setting software.
Pressing the "Print" button on this preview screen prints each motion setting.
- Print preview of RATE
It displays the print preview screen of "Rate setting" currently held on the setting software.
- Print preview of PROGRAM
It displays the print preview screen of "Program setting" currently held on the setting software.
- Print preview of BLOCK
It displays a print preview screen of setting block data in the deployment on the software.
- Print preview of SCREW NUMBER
It displays a print preview of setting screw number data in the deployment on the software.
- Print preview of Cylinder name Timer Interference
It displays a print preview of setting data Cylinder name and Timer and Interference in the deployment on the software.
- Print preview of X rate Y rate
It displays a print preview of setting X rate and Y rate data in the deployment on the software
- Print preview of X Y point
It displays a print preview of setting X Y point data in the deployment on the software.
- All settings print
It prints the all configuration data that are deployed on software.
- All settings XLS output
All configuration data that are deployed on software is output in XLS format.

8.I/O monitor

When you select "Monitor" from "I / O monitor menu", the following screen will appear. In this screen, the controller monitors signals exchanged with the PLC etc.




Fig.(8-1): I/O monitor menu

[Button]

- Monitor (F1) The monitor screen is displayed.
- Dummy input (F2) The dummy input screen is displayed.
- Dummy output (F3) The dummy output screen is displayed.
- Return to the main menu (F12) You can return to the main menu.

8-1. Monitor

When you select "Monitor" from "I / O monitor menu", the following screen will appear. In this screen, the controller monitors signals exchanged with the PLC etc.




Fig.(8-2): Monitor screen

[Item]

- Unit No.

It selects the unit number to display.

- INPUT MONITOR

Displays the input signal of the controller. Normally, a list is displayed, and when the input signal enters from the outside, the column of the input signal glows green.

- OUTPUT MONITOR

The output signal of the controller is displayed. Normally, a list is displayed, and when the GKL outputs a signal, the output signal field glows green.

[Button]

- Return to I/O monitor

You can return to the I/O monitor menu.

8-2.Dummy input

When you select "Force input" from "I / O monitor", the following screen will appear. Unlike the "monitor" screen, you can select and input the input signal from the outside. Like "Monitor" screen, "Output monitor" lights the column of the signal which is output by GKL in green.

It changes to green when input signal is selected.

Multiple input signals can be selected at the same time, and the selected signal is simultaneously input to GKL.

By pressing the "execute" button at the bottom of the screen, the signal is input to GKL.

※Unlike the "monitor" screen, please note that it will not be entered until the execute button is pressed.




Fig.(8-3): Dummy input screen

[Item]

- Unit No.

It selects the unit number to display.

- DUMMY INPUT

The input signal of the controller is displayed. Normally, the list is displayed, and select the signal to be input to GKL from this list. The column of the selected signal glows green

- OUTPUT MONITOR

The output signal of the controller is displayed. Normally, a list is displayed, and when the GKL outputs a signal, the output signal field glows green.

[Button]

- Run

It sends the selected signal to the controller. It needs the password to run. (Initial Password: 2014)

- Cancel

It clears the selected signal before transmission.

- Return to I/O monitor

You can return to the I/O monitor menu.

8-3.Dummy output

When you select "Dummy output" from "I / O monitor", it will be the following screen. It sends a signal that you specified in the configuration PC from the controller to the PLC.

When you select the input signal changes to green.

Please select the input signal, and press the Run button.

The controller forcibly outputs the signal selected at that time to the outside with SIO communication.




Fig.(8-4): Dummy output screen

[Item]

- Unit No.

It selects the unit number to display.

- Input monitor

Displays the input signal of the controller. Normally, a list is displayed, and when the input signal enters from the outside, the column of the input signal glows green.

- Dummy output

The output signal of the controller is displayed. Normally, the list is displayed, and select the signal to be output to PLC etc. from this list. The column of the selected signal glows green.

[Button]

- Run

It sends the selected signal to the controller. It needs the password to run. (Initial Password: 2014)

- Cancel

It clears the selected signal before transmission.

- Return to I/O monitor

You can return to the I/O monitor.

9.Other

9-1.About USB driver

In order to connect the GKL controller and the setting PC with the USB cable, it is necessary to make the setting personal computer recognize the GKL controller. Therefore, you need to install the specified USB driver.

Please install by executing things with OS of 32 bits ⇒ "VCP_V1.3.1_Setup.exe".

Please install by executing things with OS of 64 bit ⇒ "VCP_V1.3.1_Setup_x64.exe".

9-2. Regarding controller and setting PC connection

- Please set the COM port number used for communication with the controller to "GSS_Com =" in "C ¥ GIKEN ¥ GKL setting ¥ GKL.ini".
- Please set the version of the controller that communicates with the setting PC to "ChkIFUnitVersionSingle =" or "ChkIFUnitVersionDouble =" in "C ¥ GIKEN ¥ GKL setting ¥ GKL.ini".

9-3.About creation of tightening program

The tightening program can be created in the following way.




Fig.(9-1): About the tightening program creation method

9-4. About Operation preparation OFF of configuration reading

This section describes Operation preparation OFF at the time of reading and writing configuration.

Operation preparation OFF is done in order to ensure the time of the reading and writing of data.

The following table shows how read and write operations on whether the operation preparation OFF is necessary.

○: not need , ×: need

• When the setting read

Overall setting	○
Nut runner setting (Rate setting, Block control, SOC.T, PRE.T, REV.T, REA.T)	○
Unit setting	○
Tightening data output setting	○
Option setting	○
Screw number setting	○
Program setting	○
Position setting(Cylinder name, X rate, Y rate, Interference)	○
XY Point	○
Timer setting	○
Tightening record	×

• When the setting write

Overall setting	×
Nut runner setting (Rate setting, Block control, SOC.T, PRE.T, REV.T, REA.T)	×
Unit setting	×
Tightening data output setting	×
Option setting	×
Screw number setting	×
Program setting	×
Position setting(Cylinder name, X rate, Y rate, Interference)	×
Timer setting	×
XY Point	△ (Note1)

(Note1) With judgment OFF, each individual operation is unnecessary.

The terminology explanation

- Unit

GKL allows each axis up to 30 axes to operate independently, or it can treat several axes as one "unit".

GKL can control up to seven units with one interface unit.

A controller belongs to at least one axis (1 unit at maximum 30 axes) for one unit.

Then, all the axes belonging to one unit are started simultaneously by one input command.

In SIO, another station number is allocated to each unit for GKL.

- Program

The screw tightening program can have 16 programs of 220 steps for 30 axes.

Before entering the program setting, these maximum values can be selected

from the following ① to ③ which is a combination of axis, program, step maximum value on the program Max value selection screen.

① 30 axes, 16 program No., 220 steps.

② 30 axes, 50 program No., 70 steps,

③ 8 axes, 50 program No., 220 steps

One program starts with the control flag (synchronous etc) and the rated setting, you can set the operation of maximum 220 steps.

(It changes according to the setting of the program Max value selection screen.)

However, it treats the end as one step.

At least one block must be set in the program.

- Block

The block is an operation group of the screw tightening program.

On the setting PC, you can set each action and see the setting value of the block operation with the waveform image.

In the program setting, the block is inserted with a rated screw number, zero check, etc.

In the program setting, the inserted block starts from the rating and shows a block until the end step.

In automatic operation, one block is executed by one program start.

In the block end step, the judgment (block OK / NG) for the operated block is output.

If it becomes "NG" at any step in the block, it becomes "block NG" judgment (except when there is a retry), the next step in the block will not be executed.

- Step

Each operation(SOC.T, PRE.T, REV.T, REA.T) in the program, end, and retry are called steps. One or more blocks are required in the program. The program runs from step 1 and ends at the end of the last block. In the final block end step, comprehensive judgment (total OK / NG) is output. Each axis in the unit operates in step synchronization. In addition, the servo is turned off for the axes that have completed the step and wait for the step action to complete of the other axes. Once all axis steps have been completed, the next step will work.

- QL input

If the screw tightening operation is not within the OK range in the block performing the tightening operation, "NG" is output for that block. At this time, judgment "NG" can be changed to "OK" by inputting the tightening output of the torque wrench with limit switch to the controller. This input is called "QL input".

- Retry

Using this function, when each action(SOC.T, PRE.T, REV.T, REA.T) in the block becomes NG, you can perform the retry operation. When retry is set on the step, GKL executes the operation from the retry step to the end step when NG occurs from the block start to the step before the retry step. If NG does not occur, the process jumps from the retry step to the end step, and the subsequent operation is not executed.

- **SOC.T**
This operation is used for the crown action of the socket and screw before tightening and for the socket sticking prevention action after screw tightening.
- **PRE.T**
This is an operation to perform temporary attachment until the screw is seated.
- **REV.T**
This motion is an operation to loosen the screw after seating a few turns. By monitoring the residual torque at the time of this loosening operation, it is possible to judge the seizing of the bolt.
- **Rea.T**
This is the final tightening operation to tighten the screw to the target torque.
- **Tightening data output setting**
You can connect the interface unit and the PLC by serial communication, exchange engine numbers, set calendar, send result data, etc.
- **Tightening sampling operation**
It rotates in a tightening direction at a constant speed and ends when it reaches "tightening sampling stop torque".
By this operation, information to be used for "tightening sampling setting" of "Auto setting" is collected.
- **End synchronization**
With this synchronization, after completion of the PRE.T or REA.T, it will tighten until it reaches the end torque at 5 rpm.
- **Stretching waveform**
This is the waveform of the amount of torque increase for each fixed angle from the start torque of angle measurement to the cut torque.

The revise history

Version	Change contents	notes
The 1st edition	Creation	18.12.01
The 2 nd edition	Contact information update	20.03.11



■ Headquarters

97-8, Imago-cho Yamatokoriyama, Nara, 639-1031

TEL : +81-743-59-3730

E-Mail (Sales engineering department) : gyomu@gikenkogyo.com

E-Mail (Control engineering section) : seigyو@gikenkogyo.com

■ Nagoya Branch Office

1202, Kumada, Nagakute, Aichi, 480-1144

TEL : +81-561-63-5321

E-Mail : nagoya@gikenkogyo.com

■ Kanto Branch Office

1-2-15, Matoba, Kawagoe-city, Saitama, 350-1101

TEL : +81-49-298-4755

E-Mail : kanto@gikenkogyo.com

The 2nd edition